

Onan

**Parts
Manual**
DL6
GenSet




Onan Service Parts

934-0231
3-89 (SPEC C-E)
Replaces 6-88 (Spec C-E)
Printed in U.S.A

General Information

For parts or service, contact the dealer from whom you purchased this equipment or refer to your Nearest Authorized Onan Parts and Service Center.

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO. and SERIAL NO. from the Onan nameplate.



A diagram of an Onan nameplate. It is a rectangular plate with two circular mounting holes at the top. The Onan logo is at the top left. Below it is a large rectangular box labeled "MODEL AND SPEC NO.". Below that is a smaller rectangular box labeled "SERIAL NO.". The bottom right corner of the plate is folded over, revealing another layer. The text "M-1149" is printed at the bottom right of the diagram.

For handy reference, insert "YOUR" nameplate information in the spaces above.

Important Safety Precautions

Read and observe these safety precautions when using or working on electric generators, engines and related equipment. Also read and follow the literature provided with the equipment.

Proper operation and maintenance are critical to performance and safety. Electricity, fuel, exhaust, moving parts and batteries present hazards that can cause severe personal injury or death.

FUEL, ENGINE OIL, AND FUMES ARE FLAMMABLE AND TOXIC

Fire, explosion, and personal injury can result from improper practices.

- Used engine oil, and benzene and lead, found in some gasoline, have been identified by government agencies as causing cancer or reproductive toxicity. When checking, draining or adding fuel or oil, do not ingest, breathe the fumes, or contact gasoline or used oil.
- Do not fill tanks with engine running. Do not smoke around the area. Wipe up oil or fuel spills. Do not leave rags in engine compartment or on equipment. Keep this and surrounding area clean.
- Inspect fuel system before each operation and periodically while running.
- Equip fuel supply with a positive fuel shutoff.
- Do not store or transport equipment with fuel in tank.
- Keep an ABC-rated fire extinguisher available near equipment and adjacent areas for use on all types of fires except alcohol.
- Unless provided with equipment or noted otherwise in installation manual, fuel lines must be copper or steel, secured, free of leaks and separated or shielded from electrical wiring.
- Use approved, non-conductive flexible fuel hose for fuel connections. Do not use copper tubing as a flexible connection. It will work-harden and break.

EXHAUST GAS IS DEADLY

- Engine exhaust contains carbon monoxide (CO), an odorless, invisible, poisonous gas. Learn the symptoms of CO poisoning.
- Never sleep in a vessel, vehicle, or room with a genset or engine running unless the area is equipped with an operating CO detector with an audible alarm.
- Each time the engine or genset is started, or at least every day, thoroughly inspect the exhaust system. Shut down the unit and repair leaks immediately.

- Warning: Engine exhaust is known to the State of California to cause cancer, birth defects and other reproductive harm.

Make sure exhaust is properly ventilated.

- Vessel bilge must have an operating power exhaust.
- Vehicle exhaust system must extend beyond vehicle perimeter and not near windows, doors or vents.
- Do not use engine or genset cooling air to heat an area.
- Do not operate engine/genset in enclosed area without ample fresh air ventilation.
- Expel exhaust away from enclosed, sheltered, or occupied areas.
- Make sure exhaust system components are securely fastened and not warped.

MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Do not remove any guards or covers with the equipment running.
- Keep hands, clothing, hair, and jewelry away from moving parts.
- Before performing any maintenance, disconnect battery (negative [–] cable first) to prevent accidental starting.
- Make sure fasteners and joints are secure. Tighten supports and clamps, keep guards in position over fans, drive belts, etc.
- If adjustments must be made while equipment is running, use extreme caution around hot manifolds and moving parts, etc. Wear safety glasses and protective clothing.

BATTERY GAS IS EXPLOSIVE

- Wear safety glasses and do not smoke while servicing batteries.
- Always disconnect battery negative (–) lead first and reconnect it last. Make sure you connect battery correctly. A direct short across battery terminals can cause an explosion. Do not smoke while servicing batteries. Hydrogen gas given off during charging is explosive.
- Do not disconnect or connect battery cables if fuel vapors are present. Ventilate the area thoroughly.

DO NOT OPERATE IN FLAMMABLE AND EXPLOSIVE ENVIRONMENTS

Flammable vapor can be ignited by equipment operation or cause a diesel engine to overspeed and become difficult to stop, resulting in possible fire, explosion, severe personal injury and death. **Do not operate diesel equipment where a flammable vapor environment can be created by fuel spill, leak, etc., unless equipped with an automatic safety device to block the air intake and stop the engine.**

HOT COOLANT CAN CAUSE SEVERE PERSONAL INJURY

- Hot coolant is under pressure. Do not loosen the coolant pressure cap while the engine is hot. Let the engine cool before opening the pressure cap.

ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Do not service control panel or engine with unit running. High voltages are present. Work that must be done while unit is running should be done only by qualified service personnel.
- Do not connect the generator set to the public utility or to any other electrical power system. Electrocution can occur at a remote site where line or equipment repairs are being made. An approved transfer switch must be used if more than one power source is connected.
- Disconnect starting battery (negative [-] cable first) before removing protective shields or touching electrical equipment. Use insulative mats placed on dry wood platforms. Do not wear jewelry, damp clothing or allow skin surface to be damp when handling electrical equipment.
- Use insulated tools. Do not tamper with interlocks.
- Follow all applicable state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag open switches to avoid accidental closure.
- With transfer switches, keep cabinet closed and locked. Only authorized personnel should have cabinet or operational keys. Due to serious shock hazard from high voltages within cabinet, all service and adjustments must be performed by an electrician or authorized service representative.

If the cabinet must be opened for any reason:

1. Move genset operation switch or Stop/Auto/Handcrank switch (whichever applies) to Stop.
2. Disconnect genset batteries (negative [-] lead first).
3. Remove AC power to automatic transfer switch. If instructions require otherwise, use extreme caution due to shock hazard.

MEDIUM VOLTAGE GENERATOR SETS (601V TO 15kV)

- Medium voltage acts differently than low voltage. Special equipment and training are required to work on or around medium voltage equipment. Operation and maintenance must be done only by persons trained and qualified to work on such devices. Improper use or procedures will result in severe personal injury or death.
- Do not work on energized equipment. Unauthorized personnel must not be permitted near energized equipment. Induced voltage remains even after equipment is disconnected from the power source. Plan maintenance with authorized personnel so equipment can be de-energized and safely grounded.

GENERAL SAFETY PRECAUTIONS

- Do not work on equipment when mentally or physically fatigued or after consuming alcohol or drugs.
- Carefully follow all applicable local, state and federal codes.
- Never step on equipment (as when entering or leaving the engine compartment). It can stress and break unit components, possibly resulting in dangerous operating conditions from leaking fuel, leaking exhaust fumes, etc.
- Keep equipment and area clean. Oil, grease, dirt, or stowed gear can cause fire or damage equipment by restricting airflow.
- Equipment owners and operators are solely responsible for operating equipment safely. Contact your authorized Onan/Cummins dealer or distributor for more information.

KEEP THIS DOCUMENT NEAR EQUIPMENT FOR EASY REFERENCE.

Index

- Actuator, Electronic Governor 13
- Adapter, Oil Filter 22
- Alternator 34
- Alternator - Components 35
- Belt, Alternator 34
- Block, Cylinder 6
- Board, PC - Alarm Relay 68
- Board, PC - Magnetic Pickup 77
- Board, PC - Over/Under Voltage Sensor 68
- Board, PC - Time Delay 68
- Box, Output - Spec C and D 56
- Box, Output - Spec E 60
- Breaker, Circuit - AC 56
- Breaker, Circuit - Control Mounted - Spec C and D 72
- Breaker, Circuit - Control Mounted - Spec E 74
- Breaker, Circuit - Electronic Governor 13
- Cable, Battery 36
- Cable, Pickup - Magnetic - Electronic Governor 13
- Camshaft 6
- Cap, Oil Fill - Gearcase 23
- Cap, Oil Fill - Rocker Cover 23
- Cap, Pressure 44
- Capacitor 58
- Chassis 51
- Clamp, Injection Line 14
- Cleaner, Air - Heavy Duty 25
- Cleaner, Air - Housed Sets 26
- Cleaner, Air - Oil Bath 27
- Cleaner, Air - Standard 24
- Connection, Coolant Heater 30
- Connector, Coolant Outlet 30
- Control, Electronic Governor 13
- Control, Generator Set - Spec C and D 66
- Control, Generator Set - Spec E 68
- Control, Vernier Throttle 12
- Cover, Rocker 23
- Crankshaft 6
- Dampener, Vibration - Control Box - Spec C and D 58
- Door, Control - AC - Spec E 74
- Door, Control - DC - Spec E 75
- Drain, Oil 21
- Element, Air Cleaner - Heavy Duty 25
- Element, Air Cleaner - Housed Sets 26
- Element, Air Cleaner - Standard 24
- Element, Water Separator 18
- Fan, Cooling 44
- Filter, Fuel 17
- Filter, Oil 22
- Flange, Exhaust 29
- Flywheel 33
- Gauges - DC - Spec C and D 72
- Gauges - DC - Spec E 75
- Gear, Injection Pump 10
- Gearcase 10
- Generator 54
- Governor, Electronic 13
- Guard, Belt - Remote Radiator 43
- Guard, Belt - Standard 44
- Guard, Fan 44
- Guard, Radiator 44
- Harness, Wiring - AC Door - Spec E 68
- Harness, Wiring - Alarm Relay 68
- Harness, Wiring - DC Door - Spec E 68
- Harness, Wiring - Engine to Control - Spec C and D 56
- Harness, Wiring - Engine to Control - Spec E 60
- Harness, Wiring - Generator Control Panel - Spec C and D 72
- Harness, Wiring - Generator to Control - Spec C and D 56
- Harness, Wiring - Generator to Control - Spec E 60
- Harness, Wiring - Magnetic Pickup 77
- Harness, Wiring - Over/Under Voltage Sensor 68
- Harness, Wiring - Remote Control - Spec C and D 66
- Harness, Wiring - Time Delay 68
- Harness, Wiring - Voltage Regulator - VRA21 70
- Harness, Wiring - Watts Transducer 74
- Head, Cylinder 8
- Heater, Control - Spec C and D 64
- Heater, Control - Spec E 65
- Heater, Engine Tank 40
- Heater, Generator 63
- Hood, Air Cleaner - Heavy Duty Air Cleaner 25
- Hood, Air Cleaner - Oil Bath Air Cleaner 27
- Hose, Radiator 44
- Housing, Flywheel 32
- Housing, Generator Set 52
- Housing, Radiator 44
- Indicator, Oil Level 20
- Indicator, Service - Air Cleaner - Housed Sets 26
- Indicator, Service - Heavy Duty Air Cleaner 25
- Indicator, Service - Oil Bath Air Cleaner 27
- Injector, Fuel 14
- Isolator, Vibration - Control - Spec E 68
- Kit, Gasket - Lower End 6,78
- Kit, Gasket - Valve Grind 8,78
- Kit, Repair - Coolant Pump 31
- Kit, Repair - Fuel Transfer Pump 17
- Light, Indicator - Control Panel - Spec C and D 72
- Light, Indicator - DC Control Door - Spec E 75
- Light, Indicator - Upper/Lower Scale 74
- Line, Fuel - Fuel Return 14
- Line, Fuel - Fuel Supply 17
- Line, Fuel - Water Separator 18
- Line, Injection 14
- Manifold, Exhaust 29
- Manifold, Intake 28
- Meters - AC - Spec C and D 72
- Meters - AC - Spec E 74
- Monitor, Engine - Spec C and D 66
- Monitor, Engine - Spec E 68
- Mount, Engine - Front 38
- Mount, Vibration - Engine 51
- Muffler 41

Index

- Paint - Touch Up 78
- Pan, Oil 20
- Panel, Control - Generator Set - Spec C and D 72
- Pickup, Magnetic 77
- Pickup, Oil 20
- Piston 6
- Plug, Glow 38
- Pulley, Alternator 34
- Pulley, Coolant Pump 31
- Pulley, Crankshaft 31
- Pump, Coolant 31
- Pump, Fuel - Electric 46
- Pump, Fuel Transfer 17
- Pump, Injection 14
- Pump, Injection - Components 16
- Pump, Oil 10

- Radiator 44
- Regulator, Voltage - Spec C and D 66
- Regulator, Voltage - Spec E 68
- Regulator Assembly, Voltage - VRA21 Components 70
- Regulator Assembly, Voltage - VRAS-2 Components 71
- Relay - Day Tank - Overhead Fuel Supply Application 48
- Relay - Day Tank - Underground Fuel Supply Application 46
- Relay - Electronic Governor 13
- Relay, Run 76
- Relay, Solenoid - Heater 51
- Relay, Solenoid - Start 51
- Relays - Control Mounted - Spec C and D 66

- Sealant, Thread 78
- Sender, Oil Pressure 39
- Sender, Oil Temperature 22
- Sender, Water Temperature 31
- Sensor, Speed - Magnetic - Electronic Governor 13
- Sensor, Speed - Magnetic - Overspeed Switch 77
- Separator, Water 18
- Separator, Water - Components 19
- Shield, Heat - Exhaust 41
- Shroud, Fan 44
- Solenoid, Fuel - Day Tank 49
- Spacer, Fan 44
- Starter 36
- Starter - Components 37
- Strap, Ground - Control - Spec C and D 66
- Strap, Ground - Control - Spec E 68
- Strap, Ground - Engine 51
- Switch - Emergency Stop 75
- Switch, Low Coolant Level 45
- Switch, Low Engine Temperature 8
- Switch, Oil Pressure 39
- Switch, Overspeed - With Magnetic Pickup 77
- Switch, Overspeed - Without Magnetic Pickup 54
- Switch, Rocker - Spec C and D 72
- Switch, Rocker - Spec E 75
- Switch, Rotary - Spec C and D 72
- Switch, Rotary - Spec E 74
- Switch, Thermostat 31

- Tank, Day - Overhead Supply Application 48
- Tank, Day - Underground Supply Application 46
- Tank, Fuel - Skid Mounted 50
- Thermostat 31
- Transducer, Watt 68
- Transformer, Current 58
- Tube, Air Intake - Heavy Duty Air Cleaner 25
- Tube, Air Intake - Housed Sets 26
- Tube, Air Intake - Oil Bath Air Cleaner 27
- Tube, Exhaust 41
- Tube, Oil Fill - Gearcase 23

Introduction

This parts manual applies to the standard generator sets as listed below. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Unless otherwise mentioned in the description or page heading, parts are interchangeable between models. All references in the parts description or page heading that pertain to specification letter differences for replacement parts are for the model listed on the identification label affixed to the generator set control. Throughout this manual left (non-accessory) and right (accessory) sides are determined by facing the rear or generator end of the set.

Generator Set Data Table


MODEL IDENTIFICATION	RATING	MODEL IDENTIFICATION	RATING
20.0 DL6-*/#②	20,000 WATTS	25.0 DL6-*/#②	25,000 WATTS
30.0 DL6-*/#②	30,000 WATTS		

Electrical Data Table

*VOLTAGE CODES	VOLTS	HERTZ	WIRE	PHASE	NOTES
(3AR)	100/200	60	4	1	+
B (3R)	120/240	60	4	1	
(7R)	220/380	60	4	3	
(9XR)	347/600	60	4	3	
L (15R)	120/208	60	12	3	
	120/240				+
	127/220				
	139/240				
	240/416				
	254/440				
	277/480				
(53R)	120/240	50	4	1	
(515R)	110/190	50	12	3	
	110/220				
	115/200				
	115/230				
	120/208				
	127/220				
	220/380				
	230/400				
	240/416				
	254/440				

- * - Voltage codes follow model letter designations. A letter is now used in the model to indicate the voltage codes and replaces the corresponding number and letter designations (in brackets) as listed in the Electrical Data Table column. (Example: 30.0 DL6-L/ was formerly 30.0 DL6-15R/) The letter designation is used beginning with Spec E models.
- # - Specification number: Number 1 is standard, all others indicate variations.
- ② - Specification letter: Letter advances (C to D, D to E, etc.) with major manufacturing changes.
- + - These generators are reconnectable, refer to Operator's Manual for wiring data.

Cylinder Block



267A


Cylinder Block

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	110-3292	1	Block Assembly, Cylinder (Includes Parts Marked *)	26	114-0316	6	Bushing, Connecting Rod (Semi-Finished)
2	110-2978	2	*Pin, Cylinder Head Alignment	27	114-0315	12	Bolt, Connecting Rod
3	720-1801	14	*Screw, Cap - Hex Head - Special	28	114-0318	12	Nut, Connecting Rod
4	740-1801	14	*Washer, Flat - Special	29			Bearing, Connecting Rod (Half)
5			Plug, Cup		114-0319	12	Standard
	517-0141	6	* 50.8 MM Stainless Steel		114-0319-01	12	0.25 MM Undersize
	517-0144	2	* 12.7 MM Steel		114-0319-02	12	0.50 MM Undersize
	517-0146	1	* 31.75 MM Stainless Steel		114-0319-03	12	0.75 MM Undersize
	517-0250	1	54.37 MM Stainless Steel (Oversize)	30			Piston And Pin Kit (Includes Retaining Rings)
6	517-0140	1	*Plug, Welch (57.15 MM) Steel		112-0201	6	Standard
7			Pin, Alignment		112-0202	6	0.25 MM Oversize
	775-0074	2	* 8 MM x 20 MM		112-0203	6	0.50 MM Oversize
	775-0089	2	* 10 MM x 20 MM		112-0204	6	0.75 MM Oversize
	775-0078	2	* 8 MM x 40 MM		112-0205	6	1.0 MM Oversize
8	101-0511	1	*Bearing, Camshaft - Front	31	112-0165	6	Pin, Piston
9	101-0471	6	*Bearing, Camshaft - Inter- mediate and Rear	32	518-0409	12	Ring, Retaining - Piston Pin
15	505-0274	6	*Plug, Pipe - Steel (1/8")	33			Ring Kit, Piston
16	516-2102	1	*Pin, Regulator Valve Spring		113-0233	6	Standard
17	123-1514	1	*Piston, Regulator Valve		113-0234	6	0.25 MM Oversize
18	123-1511	1	*Spring, Regulator Valve		113-0235	6	0.50 MM Oversize
19	740-1004	1	*Washer, Flat (M6)		113-0236	6	0.75 MM Oversize
20			Bearing Kit, Main (Includes Upper and Lower Bearing Half)		113-0237	6	1.0 MM Oversize
			Front	34	104-1576	1	Crankshaft and Gear (Includes Key)
	101-0689	1	Standard	35	168-0173	1	Kit, Gasket - Lower End
	101-0690	1	0.25 MM Undersize	36	104-1138	1	Gear, Crankshaft
	101-0691	1	0.50 MM Undersize	37	515-0245	1	Key - Crankshaft Gear
	101-0692	1	0.75 MM Undersize	38	101-0713	1	Plate, Rear Seal (Includes Seal)
			Center	39	509-0203	1	Seal, Oil - Rear (Includes Wear Sleeve)
	101-0681	1	Standard	40	101-0600	1	Gasket, Rear Seal Plate
	101-0682	1	0.25 MM Undersize	41	718-1037	8	Screw, Cap - Hex Head (M8 x 25 MM)
	101-0683	1	0.50 MM Undersize	42	740-1006	8	Washer, Flat (M8)
	101-0684	1	0.75 MM Undersize	43	105-0512	1	Camshaft
			Intermediate (Except Center)	44	105-0515	1	Gear, Camshaft
	101-0685	4	Standard	45	105-0534	1	Retainer, Camshaft
	101-0686	4	0.25 MM Undersize	46	515-0245	1	Key - Camshaft Gear
	101-0687	4	0.50 MM Undersize	47	115-0275	12	Tappet
	101-0688	4	0.75 MM Undersize	48	504-0028	1	Valve, Coolant Drain (3/8") Spec C
			Rear				
	101-0677	1	Standard				
	101-0678	1	0.25 MM Undersize				
	101-0679	1	0.50 MM Undersize				
	101-0680	1	0.75 MM Undersize				
25	114-0313	6	Rod, Connecting (Includes Finished Bearing, Bolts and Nuts)				

* - Parts Included in 110-3292 Cylinder
Block Assembly

* - Parts Included in 110-3292 Cylinder Block Assembly

Cylinder Head




279A

Cylinder Head

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	110-3200	1	Head Assembly, Cylinder (Includes Guides, Seats, Cup Plugs, Breather Tubes, Valves, Springs, Water Pump Adapter, Retainers, Collets, Wear Plates, Sleeves, Seals and Spacers)	11	110-2991	12	Plate, Valve Spring Wear Spec C
2	110-3284	1	Head, Cylinder (Includes Water Pump Adapter, Seats, Spacers, Sleeves, Cup Plugs and Guides)	12	110-2991	6	Begin Spec D (Exhaust)
3	110-3495	6	Guide, Valve (Semi-Finished)	12	110-3432	6	Spacer, Valve Spring (Intake) Begin Spec D
4	110-3496	6	Intake (Standard)	13	110-3228	12	Seal Assembly, Valve Stem
			Exhaust (Standard)	14	110-2979	6	Sleeve, Sealing
			Seat, Valve	15	309-0269	1	Switch, Low Engine Temperature (S4) Controls With 9 or 12 Indicator Lights
			Intake (Not Original Equipment)	16	720-1802	26	Screw, Cap - Hex Head (M12 x 130 MM)
	110-2839	6	Spec C	17	740-1801	20	Washer, Flat (M12)
			Begin Spec D	18	110-3026	1	Gasket, Cylinder Head
	110-3226-01	6	Standard	19			Stud, Rocker Arm
	110-3226-02	6	.25 MM Oversize		115-0204	6	Short
	110-3226-03	6	.50 MM Oversize		115-0270	6	Long
			Exhaust	20	115-0313	3	Guide, Push Rod
	110-2781-01	6	Standard	21	508-0228	3	Grommet
	110-2781-02	6	.25 MM Oversize	22	115-0253	12	Pushrod
	110-2781-03	6	.50 MM Oversize	23	120-0920	1	Tube, Rocker Arm Oil
5			Plug, Cup	24	502-0003	1	Connector, Inverted Male
	517-0142	11	38.1 MM	25	115-0316	12	Arm, Rocker
	517-0146	4	31.75 MM	26	115-0202	12	Ball, Rocker Arm
	517-0162	6	19.05 MM	27	526-2119	12	Washer, Flat
6	110-3137	6	Plug, Hot (Swirl)	28	115-0315	12	Locknut, Rocker Arm
7			Valve	29			Adapter, Water Pump
	110-3066	6	Intake		110-3045	1	Standard
	110-2840	6	Exhaust		110-3490	1	0.5 MM Oversize
8	110-3300	12	Spring, Valve	30	123-1536	2	Tube, Breather
9	110-3015	12	Retainer, Valve Spring	31	800-2085	1	Screw, Cap - Hex Head (M10 x 20 MM)
10	110-2752	24	Collet, Valve Lock	32	740-1008	1	Washer, Flat (M10)
				33	110-3245	12	Cap, Valve Stem
				34	517-0167	1	Plug, Cup (22.6 MM)
				35	168-0160	1	Kit, Gasket - Valve Grind

Gearcase




22A

Gearcase

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	105-0513	1	Gear, Idler (Includes Finished Bearing)	19	740-1006	7	Washer, Flat (M8)
2	105-0519	1	Bearing, Idler Gear (Semi-Finished)	20	103-0746	1	Gearcase (Includes Oil Seal and Oil Fill Tube)
3	105-0508	1	Shaft, Idler Gear	21	509-0191	1	Seal, Oil (Includes Wear Sleeve)
4	526-2127	1	Washer, Flat (M10)	22	103-0731	1	Gasket, Gearcase
5	718-1064	1	Screw, Cap - Hex Head (M10 x 75 MM)	23	718-1046	2	Screw, Cap - Hex Head M8 x 70 MM
6	103-0716	1	Backplate, Gearcase		718-1043	5	M8 x 55 MM
7	120-0983	1	Shaft, Oil Pump Idler Gear	24			Washer, Flat
8	120-0885	1	Gear, Oil Pump Drive		740-1006	4	M8
9	718-1035	1	Screw, Cap - Hex Head (M8 x 16 MM)		740-1010	4	M12
10	526-2106	1	Washer, Flat	25	103-0735	1	Cover, Injection Pump Gear
11	120-1063	1	Gear, Oil Pump Idler (Includes Finished Bearing)	26	509-0263	1	Seal, O-Ring
12	120-1041	1	Bearing, Oil Pump Idler Gear (Semi-Finished)	27			Screw, Cap - Hex Head
13	526-2107	1	Washer, Flat		718-1048	1	M8 x 80 MM
14	718-1035	1	Screw, Cap - Hex Head (M8 x 16 MM)		718-1044	2	M8 x 60 MM
15	725-1802	1	Screw, Hex Socket Set (M16 x 16 MM)		718-1036	1	M8 x 20 MM
16	103-0733	1	Gasket, Gearcase Backplate	28	103-0750	1	Plate, Timing
17			Screw, Cap - Hex Head	29	147-0427	1	Gear, Injection Pump
	718-1037	1	M8 x 25 MM	30	815-0578	2	Screw, Cap - Hex Head (M6 x 12.5 MM)
	718-1039	1	M8 x 35 MM	31	718-1043	2	Screw, Cap - Hex Head (M8 x 55 MM)
18	725-1801	2	Screw, Low Socket Head Cap (M8 x 16 MM)	32	120-0979	1	Bearing, Oil Pump Drive Shaft
				33	120-1014	1	Pump Kit, Oil (Includes Drive Shaft Bearing)


Vernier Throttle Control



217B

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	152-0157	1	Control, Vernier (51")	7	526-0052	1	Washer, Flat (1/4")
2	142-0114	1	Clip, Control Mounting	8	152-0158	1	Swivel
3	821-0018	2	Screw, Locking - Hex Washer Head (1/4-20 x 5/8")	9	815-0104	1	Screw, Machine - Fillister Head (#8-32 x 5/16")
4	870-0212	2	Nut, Self-locking - Hex (1/4-20)	10	151-0230	1	Bracket, Control Mounting
5	813-0103	1	Screw, Machine - Round Head - (#10-32 x 3/4")	11	148-0274	1	Clip, J
6	870-0131	1	Nut, Hex - With ET (#10-32)	12	152-0282	1	Bracket, Control Mounting


Electronic Governor



205C

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	151-0566	1	Actuator, Governor	12	813-0103	5	Screw, Machine - Round Head (#10-32 x 3/4")
2	800-0006	4	Screw, Cap - Hex Head (1/4-20 x 7/8")	13	850-0030	5	Washer, Lock - Spring (#10)
3	850-0040	4	Washer, Lock - Spring (1/4")	14	338-1705	1	Harness, Wiring - Includes Relay
4	150-1996	1	Bracket, Mounting	15	307-1886	1	Relay
5	151-0567	1	Arm, Governor (Includes Screw and Nut)	16	320-0540	1	Breaker, Circuit - 15 Amp (CB13) Includes Mounting Nuts
6	150-1923	1	Rod, Governor Control	17	338-1765-01	1	Cable, Magnetic Pickup (60")
7	800-2071	4	Screw, Cap - Hex Head (M8 x 90 MM)	18	151-0603-02	1	Sensor, Magnetic Speed
8	870-0131	2	Nut, Hex - with ET (#10-32)	19	800-0007	1	Screw, Cap - Hex Head (1/4-20 x 1")
9	150-0939	2	Joint, Ball	20	870-0065	1	Nut, Self-Locking (1/4-20)
10	151-0437	1	Kit, Throttle Modification (Fuel Injection Pump)	21	147-0779	1	Sleeve, Throttle Stop
11	151-0565	1	Control, Governor (A12) (Includes Jumper)	22	130-1107	2	Spacer

Fuel Injection




256A

Fuel Injection

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Pump, Fuel Injection (See Separate Page for Components)	16			Washer, Injection Nozzle Shim
	147-0464-05	1	1800 RPM		147-0617	As Req.	0.80 MM
	147-0464-06	1	1500 RPM		147-0618	As Req.	0.84 MM
2	520-2403	3	Stud, Injection Pump (M8)		147-0619	As Req.	0.88 MM
3	526-2106	3	Washer, Flat (M8)		147-0620	As Req.	0.92 MM
4	750-1006	3	Nut, Hex (M8)		147-0621	As Req.	0.96 MM
5	147-0666	1	Line, Fuel Injection (No. 1)		147-0622	As Req.	1.00 MM
6	147-0667	1	Line, Fuel Injection (No. 2)		147-0623	As Req.	1.04 MM
7	147-0668	1	Line, Fuel Injection (No. 3)		147-0624	As Req.	1.08 MM
8	147-0669	1	Line, Fuel Injection (No. 4)		147-0625	As Req.	1.12 MM
9	147-0562	6	Injector, Fuel (Includes Seal)		147-0626	As Req.	1.16 MM
10	147-0436	6	Seal, Injector		147-0627	As Req.	1.20 MM
11			Clamp, Fuel Line		147-0628	As Req.	1.24 MM
	147-0672	3	Clamps Two Lines		147-0629	As Req.	1.28 MM
	147-0673	2	Clamps Three Lines		147-0630	As Req.	1.32 MM
	147-0674	1	Clamps Six Lines		147-0631	As Req.	1.36 MM
12	502-0733	1	Connector		147-0632	As Req.	1.40 MM
13	502-0057	1	Tee, Pipe - Special		147-0633	As Req.	1.44 MM
14	147-0670	1	Line, Fuel Injection (No. 5)		147-0634	As Req.	1.48 MM
15	147-0671	1	Line, Fuel Injection (No. 6)		147-0635	As Req.	1.52 MM
					147-0636	As Req.	1.56 MM
					147-0637	As Req.	1.60 MM
					147-0638	As Req.	1.64 MM
					147-0639	As Req.	1.68 MM
					147-0640	As Req.	1.72 MM
					147-0641	As Req.	1.76 MM
					147-0642	As Req.	1.80 MM
					147-0643	As Req.	1.84 MM
					147-0644	As Req.	1.88 MM
					147-0645	As Req.	1.92 MM
					147-0646	As Req.	1.96 MM
				17	147-0647	6	Tip, Nozzle
				18	147-0766	6	Banjo
				19	147-0767	12	Washer
				20	147-0765	6	Screw, Hollow
				21	501-0094	1	Line, Flexible Fuel - 60" (Fuel Return)

Fuel Injection Pump Components




20A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Pump, Fuel Injection - Complete	10	147-0584	1	Seal, Return Line Connector
	147-0464-05	1	1800 RPM	11	147-0583	1	Seal, Locking Plate
	147-0464-06	1	1500 RPM	12	147-0582	2	Seal, Pivot Shaft
1	147-0592	1	Strap, Terminal Grounding	13	147-0581	1	Seal, Advance Screw Hole Plug
2	147-0593	1	Solenoid and Frame Kit	14	147-0580	2	Seal, Head Locating Screws
3	147-0591	2	Washer, Terminal Insulating	15	147-0579	1	Connector, Return Line
4	147-0590	1	Gasket, Governor Cover	16	147-0578	1	Nut, Drive Shaft
5	147-0589	1	Clip, Shaft Retaining	17	509-0265	1	Seal, Pilot Tube
6	147-0588	2	Seal, Throttle Shaft				
7	147-0587	2	Washer, Throttle Shaft Seal				
8	147-0586	1	Washer, Guide Stud				
9	147-0585	1	Gasket, Timing Line Cover				

Note: For component parts not listed contact manufacturer shown on nameplate.


Fuel System



268A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	149-2067	1	Pump Kit, Fuel Transfer (Includes Mounting Gasket)	14	502-0736	1	Plug
2	149-1728	1	Gasket, Fuel Transfer Pump	15	502-0738	1	Connector, Male
3	718-1021	3	Screw, Cap - Hex Head (M6 x 20 MM)	16	149-1797	1	Line, Fuel
4	740-1004	3	Washer, Flat (M6)	17	149-1796	1	Line, Fuel
5	149-1732	1	Pushrod, Fuel Transfer Pump	18	149-2069	1	Repair Package - Transfer Pump
6	149-1755	1	Filter Assembly (Includes Filter, Base, Clamp, Drain Plug, Drain Seal and Plugs)	19	503-1055	1	Line, Fuel Return (Flexible) 380 MM Long
7	149-1754	1	Filter, Fuel	20	503-1054	1	Line, Fuel Return (Flexible) 25 MM Long
8	149-1801	1	Clamp, Fuel Filter	21	503-1053	5	Line, Fuel Return (Flexible) 180 MM Long
9	725-1074	2	Screw, Cap - Socket Head (M10 x 20 MM)	22	502-0773	1	Connector, Flareless Tube Fitting (Includes Sleeve and Nut)
10	740-1008	2	Washer, Flat (M10)	23	149-1835	1	Plug, Filter Drain
11	502-0774	2	Elbow, Flareless Tube Fitting (Includes Sleeve and Nut)	24	149-1836	1	Gasket, Filter Drain Plug
12	502-0153	2	Plug, Pipe (1/4")				
13	501-0441	1	Line, Flexible Fuel - 40" (Fuel Supply)				


Water Separator



211A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	149-1908-05	1	Separator, Water (Includes Filter Element) (See Separate Page for Components)	6	502-0041	1	Elbow, Male - Inverted
2	149-1914-01	1	Element	7	800-2110	2	Screw, Cap - Hex Head (M12 x 20 MM)
3	870-0257	2	Nut, Self-locking (Flange) (5/16-18)	8	850-2012	2	Washer, Lock - Spring (M12)
4	502-0029	1	Bushing, Reducer (1/4 to 1/8")	9	501-0003	1	Line, Fuel - Flexible (9")
5	502-0020	1	Elbow, Street - 90° (1/8")	10	149-1922	1	Spacer, Mounting
				11	149-2040	1	Bracket, Mounting


Water Separator Components



FS-1631-2

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	149-1908-05	1	Separator, Water (Complete)	6	149-1952	1	Plug, Vent (Includes O-Ring)
1	149-2046	1	Bowl Kit, Metal - Replacement (Includes Plug, O-Rings and Drain Assembly)	7	149-2047	1	Pump Assembly (Includes Plunger, Retainer, Shaft, Check Ball, Knob and Screw)
2	149-1953	1	Drain Assembly (Includes Knob and Seal)	8	149-2045	1	O-Ring Kit (Includes Seal and Plunger)
3	149-1914-01	1	Element (Includes Seals)				
4	502-0153	1	Plug, Hex (1/4")				
5	149-1949	1	Head Assembly - Replacement (Includes Vent Plug, O-Rings, Seal, Cap, Tube and Pump Assembly)				


Oil Pan



66A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	123-1524	1	Indicator, Oil Level	5	740-1006	4	Washer, Flat (M8)
2	120-1006	1	Pickup Kit, Oil (Includes Gasket)	6	102-1190	1	Pan, Oil
3	120-0917	1	Gasket, Oil Pickup	7	102-1036	1	Gasket, Oil Pan (Spec C and D)
4			Screw, Cap - Hex Head	8	815-0547	36	Screw, Cap - Hex Head (M8 x 20 MM) Includes Washer
	718-1046	2	M8 x 70 MM	9	541-0286	1	Kit, RTV Sealant - Oil Pan Mounting - Spec E
	718-1036	2	M8 x 20 MM				

Oil Drain Hardware




589A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0382	1	Clamp, Hose - Spec C
2	503-1276	1	Hose, Oil Drain (14") - Spec C
3	502-0415	1	Adapter, Pipe to Hose - Spec C
4	504-0011	1	Valve, Shutoff - Spec C
5	102-1235	1	Bracket, Oil Drain - Begin Spec D

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
6	502-0876	1	Cap, Pipe - Begin Spec D
7	508-0250	1	Grommet - Begin Spec D
8	501-0482	1	Line, Oil Drain (24") - Begin Spec D
9	102-1237	1	Adapter, Oil Drain - Begin Spec D
10	102-1147	1	Gasket - Begin Spec D


Oil Filter



479A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	122-0613	1	Adapter, Oil Filter (Includes Gasket)	4	122-0550	1	Filter, Oil
2	122-0635	1	Gasket, Adapter	5	725-1051	3	Screw, Cap - Socket Head (M8 x 25 MM)
3	193-0353	1	Sender, Oil Temperature (E3) Controls With 2 Indicator Lights and Oil Temperature Gauge	6	526-2108	3	Washer, Flat (M8)
				7	505-0274	1	Plug, Pipe - Countersunk (1/8")


Oil Fill



65A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	115-0346	1	Cover, Rocker	6	123-1518	1	Gasket, Oil Fill Cap
2	115-0244	1	Gasket, Rocker Cover	7	123-1558	1	Tube, Oil Fill
3	115-0320	6	Capnut, Rocker Cover	8	509-0142	1	Seal, O-Ring
4	115-0232	6	Gasket, Capnut	9	123-1647	1	Cap, Oil Fill
5	123-1605	1	Cap, Oil Fill (Includes Gasket)				


Air Cleaner (Standard)



213A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	140-1091	1	Cleaner Assembly, Air (Includes Element)	3	503-0648	1	Clamp, Hose
2	140-1089	1	Element	4	503-1181	1	Hose, Reducing
				5	503-0465	1	Clamp, Hose

Air Cleaner (Heavy Duty)




210A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0354	4	Clamp, Hose
2	503-1222	2	Elbow, 90°
3	140-1845	1	Tube, Intake
4	140-1791	1	Indicator, Service
5	140-1787	1	Hood, Air Cleaner
6	140-1841	1	Cleaner, Air (Includes Element)
7	140-1851	1	Element
8	718-1036	4	Screw, Cap - Hex Head (M8 x 20 MM)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
9	750-1006	4	Nut, Hex (M8)
10	140-0722	2	Band, Mounting
11	718-1073	1	Screw, Cap - Hex Head (M12 x 25 MM)
12	740-1006	4	Washer, Flat (M8)
13	140-1847	1	Bracket, Mounting
14	740-1010	1	Washer, Flat (M12)

Air Cleaner (Housed Sets)




603C

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	140-1841	1	Cleaner, Air (Includes Element)
2	140-1851	1	Element
3	140-0722	2	Band, Mounting
4	140-1787	1	Hood, Air Cleaner
5	140-1791	1	Indicator, Service
6	503-0625	2	Hose (2-1/2" ID x 4-1/2")

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
7	503-0867	6	Clamp, T-Bolt
8	140-2267	2	Tube, Air Inlet
9	503-1222	1	Elbow
10	821-0016	4	Screw, Self-Locking - Hex Washer Head (5/16-18 x 3/4")
11	870-0257	4	Nut, Locking - Hex Head (5/16-18)


Air Cleaner (Oil Bath)



604B

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	140-1559	1	Hood	10	503-0465	2	Clamp
2	140-2174	1	Cleaner, Air - Oil Bath	11	821-0014	4	Screw, Self-Locking - Hex Washer Head (5/16-18 x 1/2")
3	140-2233	2	Band, Mounting	12	870-0257	4	Nut, Locking - Hex Head (5/16-18)
4	503-1143	2	Clamp	13	140-2235	1	Bracket, Mounting
5	503-1084	1	Elbow, Reducer	14	821-2076	1	Screw, Self-Locking - Hex Washer Head (M12 x 25 MM)
6	140-2234	1	Tube, Air Inlet				
7	140-1260	1	Fitting, Service Indicator				
8	140-1791	1	Indicator, Service				
9	503-1074	1	Hose, Reducer				


Intake Manifold



587A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2461	1	Manifold, Intake	3	740-1006	12	Washer, Flat (M8)
	154-2604	1	Spec C and D (Includes Plug)	4	505-0274	1	Plug, Pipe (1/8")
2	718-1801	12	Spec E	5	154-2300	1	Gasket, Intake Manifold
			Screw, Cap - Hex Head				
	718-1801	6	Spec C and D (M8 x 85 MM)				
			Spec E				
	718-1801	6	M8 x 85 MM				
	718-1042	6	M8 x 50 MM				

Exhaust Manifold




259A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	154-2389	1	Manifold, Exhaust
2	154-2162	4	Gasket, Exhaust Manifold
3	800-2524	12	Screw, Cap - Hex Head (M8 x 90 MM)
4	740-1006	12	Washer, Flat (M8)
5	154-2325	1	Gasket, Exhaust Manifold

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
6	720-1072	2	Screw, Cap - Hex Head (M12 x 20 MM)
7	850-2012	2	Washer, Lock (M12)
8	155-1916	1	Flange, Exhaust
9	155-1920	1	Gasket, Exhaust Flange


Coolant Outlet Connector



207A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	309-0473	1	Cover, Thermostat(Includes Gasket)
2	725-1056	4	Screw, Cap - Socket Head (M8 x 50MM)
3	309-0424	1	Gasket, Thermostat Cover


Coolant Heater Connection (Begin Spec D)



224A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	505-0017	1	Bushing
2	502-0156	1	Elbow, Street
3	502-0153	1	Plug, Brass


Coolant Pump



199A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	131-0351	1	Kit, Coolant Pump (Includes Mounting Gaskets)	17	131-0335	1	Gasket, Backplate
2	515-0245	1	Key - Crankshaft Pulley	18	309-0462	1	Kit, Thermostat (180") Includes Cover Gasket
3	104-1472	1	Pulley, Crankshaft	19	502-0317	1	Plug, Pipe (3/4")
4	740-1006	4	Washer, Flat (M8)	20	815-0612	5	Screw, Countersunk - Flat Head - Torque Drive (Special)
5	718-1035	4	Screw, Cap - Hex Head (M8 x 16 MM)	21	309-0437	1	Switch, Thermostat - High Engine Coolant Temperature (S2) (Opens at 202" F. - Closes at 222" F.)
6	131-0342	1	Pulley, Coolant Pump	22	309-0436	1	Switch, Thermostat - High Engine Coolant Temperature (S6 - Pre-Alarm) (Opens at 196" F. - Closes at 216" F.)
7	509-0264	1	Seal, O-Ring				Controls With 7, 9 or 12 Indicator Lights
8	740-1006	3	Washer, Flat (M8)	23	541-0214-04	1	Kit, Repair (Includes Gaskets, Seal, Hub, Bearing, Impeller and Backplate Mounting Screws)
9	718-1044	3	Screw, Cap - Hex Head (M8 x 60 MM)				
10	193-0318	1	Sender, Water Temperature (E2)				
11	502-0775	1	Plug, Pipe (3/8") Controls with 2 Indicator Lights				
12	526-0283	1	Washer, Flat (M8)				
13	720-1123	1	Screw, Cap - Hex Head (M16 x 60 MM)				
14	131-0324	1	Spacer, Coolant Pump				
15	131-0294	2	Gasket, Pump Mounting				
16	309-0458	1	Kit, Thermostat (192") (Includes Cover Gasket)				


Flywheel Housing



299A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Housing, Flywheel (Includes Seal and Indicator)	3	740-1801	6	Washer, Flat (M12)
	101-0740-01	1	Spec C	4	160-1292	1	Indicator, Timing
	101-0740-02	1	Begin Spec D	5	101-0592	1	Plug, Timing Window
2	718-1078	6	Screw, Cap - Hex Head (M12 x 50 MM)	6	101-0630	1	Seal, Flywheel Housing
				7	505-2012	1	Plug, Hex
				8	740-1014	1	Washer, Flat (M16)


Flywheel1



298A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	104-1503	1	Flywheel Assembly (Includes Ring Gear and Alignment Pin)	4	720-1804	6	Screw, Cap - Flange Hex Head (M10 x 38 MM)
2	104-1185	1	Gear, Ring	5	740-1008	6	Washer, Flat (M10)
3	104-1171	1	Pin, Alignment				


Alternator



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	511-0147-13	1	Belt	12	191-1332	1	Bracket, Mounting
2	191-1339	1	Pulley	13	718-1037	4	Screw, Cap - Hex Head (M8 x 25 MM)
3	800-2060	1	Screw, Cap - Hex Head (M8 x 35 MM)	14	856-0010	1	Washer, Lock - EIT (3/8")
4	850-2008	4	Washer, Lock - Spring (M8)	15	332-1292	1	Terminal Assembly (Includes Parts Marked *)
5	526-2106	1	Washer, Flat (M8)	16	332-1281	1	*Bracket, Terminal
6	191-1541	1	Spacer	17	809-0035	1	*Screw, Sheet Metal - Round Head (#8 x 3/4")
7	191-1312	1	Strap, Adjusting	18	508-0015	1	*Washer, Fiber
8	800-2100	1	Screw, Cap - Hex Head (M10 x 100 MM)	19	870-0196	1	*Nut, Insulation
9	860-2009	1	Nut, Hex (M10)	20	740-1008	2	Washer, Flat (M10)
10	191-1321	1	Spacer				
11	191-1525	1	Alternator (37 Amp) (G1) See Separate Page for Components				


* - Parts Included in 332-1292 Terminal Assembly

Alternator Components



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	191-1525	1	Alternator (Complete) Used Beginning on Late Spec C Models - Has No Isolation Diodes on Back Side of Alternator (Replaces Early Spec C Models with Isolation Diode Assembly on Back Side of Alternator)	5			Brush Assembly Spec C
1	191-0943	1	Fan, Alternator		191-0659	1	Used on Early Spec C Models with Isolation Diode Assembly
2	191-1454	1	Diode Assembly, Isolation - Used on Early Spec C Models		191-1558	1	Used on Late Spec C Models without Isolation Diode Assembly
3			Diode, Rectifier - Negative Spec C		191-1558	1	Begin Spec D
	191-1453	1	Used on Early Spec C Models with Isolation Diode Assembly	6			Regulator, Voltage Spec C
	191-1560	1	Used on Late Spec C Models without Isolation Diode Assembly		191-1457	1	Used on Early Spec C Models with Isolation Diode Assembly
	191-1560	1	Begin Spec D		191-1557	1	Used on Late Spec C Models without Isolation Diode Assembly
4			Diode, Rectifier - Positive Spec C		191-1557	1	Begin Spec D
	191-1452	1	Used on Early Spec C Models with Isolation Diode Assembly	7	191-1556	1	Diode, Trio - Used Beginning on Late Spec C Models Without Isolation Diode Assembly
	191-1559	1	Used on Late Spec C Models without Isolation Diode Assembly				
	191-1559	1	Begin Spec D				


Starter



260A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Starter (B1) (Includes Switch Terminal Hardware) (See Separate Page for Components)	6	718-1002	1	Screw, Cap - Hex Head (M5 x 8 MM) Solenoid Terminal
	191-1394	1	Used Spec C through Early Portion of Spec D	7	850-2005	1	Washer, Lock - Spring (M5) Solenoid Terminal
	191-1888	1	Use Began During Later Portion of Spec D	8	416-0618	1	Cable, Battery - 42" (Positive)
2	720-1806	2	Screw, Cap - Flanged Hex Head (M12 x 30 MM)	9	800-2110	1	Screw, Cap - Hex Head (M12 x 20 MM)
3	740-1010	2	Washer, Flat (M12)	10	853-2012	1	Washer, Lock - ET (M12)
4	860-2008	1	Nut, Hex (M8) B+ Terminal	11	416-0530	1	Cable, Battery - 16" (Negative)
5	850-2008	1	Washer, Lock - Spring (M8) B+ Terminal				


Starter Components



575A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	191-1394	1	Starter (Complete) Used Spec C Through Early Portion of Spec D	9	191-1442	1	Stopper Set (Includes Stopper and Ring)
	191-1888	1	Use Began During Later Portion of Spec D	10	191-1441	1	Lever Assembly
1	191-1450	1	Screw Set	11	191-1440	1	Spring Set
2	191-1449	1	Bracket Assembly, Front (Includes Bearing)	12	191-1439	1	Bracket Assembly, Center
3	191-1893	2	Ring, "O" - Sealing (Used on 191-1888 Starter)	13	191-1438	1	Armature Assembly (Includes Bearings)
4	191-1430	1	Switch Assembly	14	191-1437	1	Bearing, Center
5	191-1446	1	Gear	15	191-1436	1	Bearing, Rear
6	191-1445	1	Clutch	16	191-1435	1	Yoke Assembly (Includes Pole Shoes, Field Coil and Positive Brushes)
7	191-1444	1	Cover Set (Includes Cover, Plate, Washers, Snap Ring, and Screws)	17	191-1434	1	Holder, Brush (Includes Negative Brushes)
8	191-1443	1	Pinion Set (Includes Pinion, Spring, and Stopper Set)	18	191-1433	4	Spring, Brush
				19	191-1432	1	Bracket, Rear
				20	191-1431	1	Bolt Set


Glow Plug



212A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	333-0220	6	Plug, Glow	3	750-1002	6	Nut, Hex (M5)
2	336-4131	5	Lead, Glow Plug	4	850-2005	6	Washer, Lock - Spring (M5)


Front Engine Mount



M-1548

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	403-1925	1	Bracket, Mount	3	740-1010	4	Washer, Flat (M12)
2	718-1086	2	Screw, Cap - Hex Head	4	403-1932	2	Spacer, Bracket Mounting
	718-1802	2	M12 x 90 MM (Top)				
		2	M12 x 95 MM (Bottom)				


Oil Pressure Switch



201A


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	193-0244	1	Sender, Oil Pressure (E1)	3	309-0272	1	Switch, Oil Pressure (S5 -
2			Switch, Oil Pressure -				Pre-Alarm) Closes at 20 lbs.
			Closes at 14 lbs. Descending				Descending
	309-0169	1	Spec C and D (S3)	4	505-0059	1	Tee, Pipe (1/8")
	309-0561	1	Spec E (S1)	5	505-0098	1	Nipple, Pipe (1/8" x 3/4")

Engine Tank Heater



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0183	4	Clamp, Hose (5/8")	8	870-0257	1	Nut, Self-Locking - Hex Washer Head (5/16-18)
2	503-1429-01	1	Hose, Flex (5/8")	9	333-0244-01		Heater, Engine
3	505-0020	1	Bushing, Reducer (3/4 x 1/4")		333-0244-03		1500 Watt, 120 Volt
4	505-0011	1	Elbow, Street (1/4 NPT)		856-0006	1	1500 Watt, 230 Volt
5	503-1429-05	1	Hose, Flex (5/8" x 36")				Washer, EIT (1/4")
6	130-0755	1	Bracket, Mounting				
7	821-0016	1	Screw, Self-Locking - Hex Washer Head (5/16-18 x 3/4")				


Muffler (Housed Set)



291A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	505-0454	1	Union, Pipe (2" NPT)	7	800-0036	4	Screw, Cap - Hex Head (5/16-18 x 3")
2	155-1936	1	Tube, Exhaust - Flexible	8	870-0257	4	Nut, Self-Locking - Hex Washer Head (5/16-18)
3	140-0752	2	Band, Mounting	9	526-2123	4	Washer, Flat (#10)
4	155-1931	1	Shield, Heat				
5	155-1430	4	Spacer				
6	155-1614	1	Muffler, Exhaust				


Belt Guard (With Remote Radiator)



222A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	130-3008	1	Panel, Front	7	800-2056	2	Screw, Cap - Hex Head (M8 x 16 MM)
2	800-2029	8	Screw, Cap - Hex Head (M6 x 12 MM)	8	850-2008	2	Washer, Lock - Spring (M8)
3	850-2006	9	Washer, Lock - Spring (M6)	9	191-1598	1	Guard, Alternator
4	130-3007	1	Panel, Side	10	718-1021	1	Screw, Cap - Hex Head (M6 x 20 MM)
5	130-2201	1	Bracket, Pulley Guard (Left Hand)	11	750-1004	1	Nut, Hex (M6)
6	130-2202	1	Bracket, Pulley Guard (Right Hand)				

Cooling System




573A

Cooling System

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	130-1818	1	Radiator	16	130-2160	2	Guard, Fan
2	130-1922	1	Fan	17	130-1873	1	Spacer, Fan
3	718-1032	16	Screw, Cap - Hex Head (M8 x 10 MM)	18	503-1070	1	Hose, Radiator - Lower
4	130-2154	2	Bracket, Radiator Mounting	19	870-0212	5	Nut, Lock (1/4-20)
5	718-1047	4	Screw, Cap - Hex Head (M8 x 75 MM)	20	504-0003	1	Valve, Drain
6	850-2008	20	Washer, Lock (M8)	21	191-1540	1	Guard, Alternator Belt
7	130-2150	1	Guard, Radiator	22	191-1539	1	Guard, Alternator Belt
8	800-0003	6	Screw, Cap - Hex Head (1/4-20 x 1/2")	23	191-1542	1	Bracket, Belt Guard
9	821-0010	31	Screw, Cap - Hex Head (1/4-20 x 1/2")	24	191-1543	1	Bracket, Belt Guard
10	130-2158	1	Shroud, Fan	25	191-1546	1	Guard, Alternator Belt
11	526-0021	6	Washer, Flat (1/4")	26	191-1547	1	Bracket, Alternator Belt Guard
12	130-1928	1	Cap, Pressure	27	718-1035	1	Screw, Machine - Hex Head (M8 x 16 MM)
13	503-0365	4	Clamp, Hose	28	526-2100	1	Washer, Flat (M8)
14	405-3809	1	Housing, Front	29	502-0153	1	Plug, Hex Head (1/4")
15	503-1177	1	Hose, Radiator - Upper	30	503-0429	1	Clamp
				31	517-0263	1	Cap, Radiator (Lower Hose Fitting)


Low Coolant Level Switch

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	193-0322	1	Switch - Coolant Level (S4)
2	338-1691	1	Harness, Wiring (Includes Housing)
3	323-1236	1	Housing, Connector



198A

Day Tank (Underground Fuel Supply Application)




218B

Day Tank
(Underground Fuel Supply Application)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	501-0027	2	Line, Fuel - Flexible (1/8 NPT Male x 1/4 SAE Male Swivel x 48" Lg)	12	415-0445	1	Tank, Fuel - Day (Includes Cap) (3-1/2 Gallons)
2	501-0007	1	Line, Fuel - Flexible (1/8 NPT Male x 1/4 SAE Male Swivel x 24" Lg)	13	159-0007	1	Cap - Fuel Tank
3	502-0041	2	Elbow, Pipe - Street, 90°, Brass-Inverted Male (1/4 NPT)	14	813-0098	1	Screw, Machine - Round Head (#10-32 x 3/8")
4	502-0003	2	Connector, Inverted Male (1/8")	15	850-0030	1	Washer, Lock - Spring (#10)
5	505-0007	2	Bushing, Reducer - Hex (1/4 NPT Male x 1/8 NPT Female)	16	415-0326	1	Cover, Access - Relay
6	149-1828	1	Pump, Fuel (12 VDC)	17	812-0061	2	Screw, Machine - Round Head (#6-32 x 3/8")
7	415-0321	1	Switch, Float - Liquid Level (Includes Mounting Plug)	18	870-1183	2	Nut, Self-locking, Hex - with ET (#6-32)
8	505-0054	1	Plug, Pipe - Square Head (1/4 NPT)	19	307-1157	1	Spring, Holddown - Relay
9	505-0110	1	Plug, Pipe - Square Head (3/8 NPT)	20	307-1058	1	Relay (12 VDC)
10	821-0013	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 1")	21	323-0765	1	Socket, Relay
11	415-0451	1	Strap, Retaining - Tank	22	821-0014	10	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")
				23	402-0078	4	Mount, Vibration
				24	159-1120	1	Bracket, Mounting - Fuel Tank
				25	870-0212	2	Nut, Self-locking - Hex Washer Head (1/4-20)
				26	870-0048	2	Nut, Self-locking - Hex Washer Head (5/16-18)
				27	159-1122	1	Plate, Support - Fuel Tank
				28	821-0018	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 5/8")

Day Tank (Overhead Fuel Supply Application)




219B

**Day Tank
(Overhead Fuel Supply Application)**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	501-0027	2	Line, Fuel - Flexible (1/8 NPT Male x 1/4 SAE Male Swivel x 48" Lg)	16	415-0326	1	Cover, Access - Relay
2	502-0041	1	Elbow, Inverted Male - 90° (1/4")	17	812-0061	2	Screw, Machine - Round Head (#6-32 x 3/8")
3	502-0020	1	Elbow, Pipe - Street, 90°, Brass (1/8")	18	870-1183	2	Nut, Self-locking, Hex - with ET (#8-32)
4	502-0003	1	Connector, Inverted Male (1/8")	19	307-1157	1	Spring, Holddown - Relay
5	505-0007	2	Bushing, Reducer - Hex (1/4 NPT Male x 1/8 NPT Female)	20	307-1058	1	Relay (12 VDC)
6	505-1050	1	Plug, Switch Mounting	21	323-0765	1	Socket, Relay
7	415-0466	1	Switch, Float - Liquid Level	22	821-0014	10	Screw, Self-locking - Hex Washer Head (5/16-18 x 1/2")
8	505-0054	1	Plug, Pipe - Square Head (1/4 NPT)	23	402-0078	4	Mount, Vibration
9	505-0110	1	Plug, Pipe - Square Head (3/8 NPT)	24	159-1120	1	Bracket, Mounting - Fuel Tank
10	821-0013	2	Screw, Self-locking - Hex Washer Head (1/4-20 x 1")	25	415-0516	1	Plate, Cover - Access
11	415-0451	1	Strap, Retaining - Tank	26	870-0048	2	Nut, Self-locking - Hex Washer Head (5/16-18)
12	415-0543	1	Tank, Fuel - Day (Includes Cap) (3-1/2 Gallons)	27	159-1122	1	Plate, Support - Fuel Tank
13	159-0007	1	Cap - Fuel Tank	28	505-0016	1	Bushing, Reducer (3/8" to 1/8")
14	813-0098	1	Screw, Machine - Round Head (#10-32 x 3/8")	29	307-0565	1	Solenoid - 12 VDC
15	850-0030	1	Washer, Lock - Spring (#10)	30	505-0098	1	Nipple, Pipe - Close (1/8" NPT x 3/4")
				31	800-0002	6	Screw, Cap - Hex Head (1/4-20 x 3/8")
				32	526-0063	6	Washer, Flat - Copper (17/64" ID x 7/16 OD x 1/32" Thk)
				33	309-0410	1	Valve, Float
				34	415-0467	1	Gasket - Access Plate


Fuel Tank (Skid Mounted)



215A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	502-0003	1	Adapter, Pipe - Hex (5/16-24 Female x 1/8 NPT Male)	6	821-0010	6	Screw, Self-locking - Hex Washer Head (1/4-20 x 1/2")
2	502-0041	1	Elbow, Pipe - Street, 90° (5/16-24 Female x 1/4 NPT Male)	7	159-1126	2	Strap, Retaining - Fuel Tank
3	505-0007	2	Bushing, Reducer - Hex (1/4 NPT Male x 1/8 NPT Female)	8	159-0007	1	Cap - Fuel Tank
4	505-0949	1	Plug, Pipe - Square Head (1-1/4 NPT)	9	159-1123	1	Tank, Fuel (8-1/2 Gallon)
5	505-0054	1	Plug, Pipe - Square Head (1/4 NPT)	10	501-0027	1	Line, Fuel - Flexible (1/8 NPT Male x 1/4 SAE Male Swivel x 48" Lg)
				11	159-1124	1	Tray, Mounting - Fuel Tank
				12	501-0094	1	Line, Fuel - Flexible (1/8 NPT Male x 1/4 SAE Male Swivel x 60" Lg)


Chassis



594A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	800-0091	2	Screw, Cap - Hex Head 1/2-13 x 1-1/4" (Spec C and D)	12	307-1166	1	Relay, Solenoid - Start (Lower) (K1) (Spec C and D)
	800-0090	2	1/2-13 x 1" (Spec E)	13	821-0013	1	Screw, Self-Locking - Hex Washer Head (1/4-20 x 1")
2	850-0060	9	Washer, Lock - Spring (1/2")	14	850-2012	8	Washer, Lock - Spring (M12)
3	862-0016	7	Nut, Hex (1/2-13)	15	856-0006	1	Washer, Lock - EIT (1/4")
4	402-0466	3	Mount, Vibration	16	332-1473	1	Lug, Solderless
5	337-0090	1	Strap, Ground - Engine	17	800-0091	4	Screw, Cap - Hex Head (1/2-13 x 1-1/4")
6	800-2110	1	Screw, Cap - Hex Head (M12 x 20 MM)	18	416-0813	2	Rod, J Hook (1/4-20)
7	853-2012	1	Washer, Lock - ET (M12)	19	416-0812	1	Bracket, Holddown - Battery
8	332-0602	1	Jumper, Solenoid (Spec C and D)	20	526-0219	4	Washer, Flat (1/2")
9			Screw, Self-Locking - Hex Washer Head (1/4-20 x 1/2")	21	403-1929	2	Bracket, Engine Mounting
	821-0010	8	Spec C and D	22	416-0821	1	Tray, Battery
	821-0010	6	Spec E	23	403-2053	1	Skid
10			Nut, Self-Locking - Hex Washer Head (1/4-20)	24	720-1072	8	Screw, Cap - Hex Head (M12 x 20 MM)
	870-0212	9	Spec C and D	25			Screw, Cap - Hex Head
	870-0212	7	Spec E		800-0091	3	1/2-13 x 1-1/4" (Spec C and D)
11	307-1031	1	Relay, Solenoid - Heater (Upper) (K2)		800-0090	3	1/2-13 x 1" (Spec E)

Housing




275A

Housing

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	812-0148	16	Screw, Machine - Round Head (1/4-20 x 1/2")	12	405-2677	1	Cover, Control
2	850-0040	16	Washer, Lock - Spring (1/4")	13	812-0148	4	Screw, Machine - Round Head (1/4-20 x 1/2")
3	862-0001	16	Nut, Hex (1/4-20)	14	405-3082	1	Grille
4	406-0369	4	Latch, Door	15	895-0195	-	Stripping, Weather - Bulk (Ordered by the foot - 5 foot required)
			* Begin Spec C Through a Portion of Spec D (With Mounting Holes)	16	406-0491	1	Latch, Cover
	406-0561	4	* Use Began During Spec D (Without Mounting Holes)	17	403-2064	1	Skid, Rear
5			Door, Engine	18	406-0493	4	Catch, Door
	405-2823	2	* Begin Spec C Through a Portion of Spec D (With Latch Mounting Holes)	19	405-1872	6	Clip, Door
			* Use Began During Spec D (Without Latch Mounting Holes)	20	870-0258	6	Nut, Weld (1/4-20)
	405-3306	2		21	526-0003	12	Washer, Flat (#8)
				22	818-0150	12	Rivet
6	821-0004	14	Screw, Self-locking - Hex Washer Head (10-32 x 5/16")	23	405-3070	1	Panel, Rear
7	406-0490	2	Latch, Door	24	800-0090	6	Screw, Cap - Hex Head (1/2-13 x 1")
8	821-0010	18	Screw, Self-locking - Hex Washer Head (1/4-20 x 1/2")	25	850-0060	6	Washer, Lock - Spring (1/2")
9	870-0212	12	Nut, Self-locking - Hex (1/4-20)	26	862-0016	6	Nut, Hex (1/2-13)
10	405-3060	1	Panel, Top	* - Latches and doors with mounting holes are not interchangeable with latches and doors without mounting holes.			
11	813-0098	3	Screw, Machine - Round Head (#10-32 x 3/8")				

w/mta muffler 405-4006

Generator



Generator


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	821-0010	2	Screw, Self-Locking - Hex Washer Head (1/4-20 x 1/2")	25	850-2010	20	Washer, Lock - Spring (M10)
2	150-1446	1	Bracket and Point Assembly (Includes Parts Marked #)	26	232-2418	1	Board, Terminal
3	862-0001	2	#Nut, Hex (1/4-20)	27	718-1019	4	Screw, Cap - Hex Head (M6 x 14MM)
4	853-0013	1	#Washer, Lock - ET (1/4")	28	850-2006	4	Washer, Lock - Spring (M6)
5	870-0250	1	#Nut, Insulating	29	232-2845	1	Baffle, Air
6	150-0723	1	#Point, Contact	30	800-2085	8	Screw, Cap - Hex Head (M10 x 20MM)
7	150-1445	1	#Bracket, Mounting	31	850-0040	4	Washer, Lock - Spring (1/4)
8	800-0051	1	Screw, Cap - Hex Head (3/8-16 x 1-1/4")	32			Rotor Assembly, Generator (Includes Parts Marked *)
9	856-0010	1	Washer, Lock - EIT (3/8")				20.0 DL6
10	150-0717	1	Switch, Overspeed (S3)		201-2955	1	Code 53R
11	526-0077	2	Washer, Flat (3/8")		201-2947	1	Code 515R
12	862-0003	4	Nut, Hex (3/8-16)				25.0 DL6
13	850-0050	4	Washer, Lock - Spring (3/8")		201-2955	1	Code B,3R
14			Stud		201-2947	1	Code 9XR
	520-0055	4	3/8-16 x 4"				Code L,15R
	520-0966	4	3/8-16 x 5.2"		201-2947	1	Standard
15	802-0040	4	Screw, Cap - Socket Head (1/4-20 x 2")		201-2955	1	Extended Stack
16	509-0094	1	Seal, "O" Ring		201-3048	1	Environmentally Protected
17	815-0194	2	Screw, Tapping - Hex Head With ET Lockwasher (#10-32 x 3/8")		201-2956	1	Code 53R
18			Stator Assembly, Generator (Includes Air Baffle)		201-2955	1	Code 515R
			20.0 DL6		201-2956	1	Standard
	220-3591	1	Code 53R		201-2956	1	Extended Stack
	220-3607	1	Code 515R				30.0 DL6
			25.0 DL6		201-2956	1	Code 3AR
	220-3533	1	Code B,3R		201-3050	1	Code B,3R
	220-3768	1	Code 9XR				Standard
			Code L,15R		201-2955	1	Environmentally Protected
	220-3559	1	Standard		201-2955	1	Code 7R
	220-3560	1	Extended Stack		201-2955	1	Code 9XR
	220-3587	1	Environmentally Protected		201-2956	1	Code L,15R
	220-3590	1	Code 53R		201-3049	1	Standard
			Code 515R		201-3050	1	Extended Stack
	220-3608	1	Standard				Extended Stack and Environmentally Protected
	220-3609	1	Extended Stack				
			30.0 DL6	33	805-0025	8	*Bolt, Hex Head - Slotted, Grade 8 (7/16-14 x 3/4")
	220-4086	1	Code 3AR	34	526-0249	8	*Washer, Flat - Hardened (15/32" ID x 1" OD x 1/8" Thk)
			Code B,3R				
	220-3532	1	Standard	35	232-2843	1	*Disk, Drive
	220-3998	1	Environmentally Protected	36	205-0132	1	*Fan, Generator
	220-4102	1	Code 7R	37	510-0112	1	*Bearing, Ball
	220-3769	1	Code 9XR	38	870-0284	1	*Nut, Self-Locking Hex (1-1/8-12)
			Code L,15R	39	232-2398	1	*Spacer, Bearing
	220-3560	1	Standard	40			*Rotor Assembly, Exciter (Includes Parts Marked +)
	220-3561	1	Extended Stack		201-2152	1	Standard
	220-3588	1	Environmentally Protected		201-2298	1	Environmentally Protected
	220-3589	1	Extended Stack and Environmentally Protected	41	870-0131	8	+Nut, Self-Locking - Hex With ET Lockwasher (#10-32)
19	800-0004	4	Screw, Cap - Hex Head (1/4-20 x 5/8") Exciter Stator Mounting (Early Models)	42	526-0008	12	+Washer, Flat (#10)
20	853-0013	4	Washer, Lock - ET (1/4) Exciter Stator Mounting (Early Models)	43	813-0100	4	+Screw, Machine - Round Head (#10-32 x 1/2")
21	232-2584	4	Clip, Retaining - Exciter Stator Mounting (Early Models)	44	853-0008	4	+Washer, Lock - ET (#10)
22			Stator, Exciter	45	358-0069	1	+Rectifier Assembly - Positive
	220-2010	1	Standard	46	358-0070	1	+Rectifier Assembly - Negative
	220-2309	1	Environmentally Protected	47	515-0094	1	*Key - Exciter Stator
23	211-0349	1	Bell, End				
24	800-2087	12	Screw, Cap - Hex Head (M10 x 30 MM)				

- Parts Included in 150-1446 Bracket and Point Assembly

* - Parts Included in Generator Rotor Assemblies

+ - Parts Included in Exciter Rotor Assemblies

Output Box (Spec C and D)



Output Box (Spec C and D)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	301-7381	1	Box, Output - Early Portion of Spec C (Corner brace is part of the grille)	10	323-1136	1	Plug, Circular (14 Pin) (P2)
2			Box, Output	11	323-1228	11	Pin, Male
	301-7903	1	Late Portion of Spec C (Corner brace is part of output box)	12			Breaker, Circuit (CB4 or CB5) 50 Hertz
	301-7903	1	Spec D		320-1061	1	Voltage Code 53R - 125 Amp, 240 Volt
3	301-7336	1	Grille - Early Portion of Spec C (Corner brace is part of grille)		320-0638	1	Voltage Code 515R 40 Amp, 480 Volt
4			Grille		320-0645	1	50 Amp, 480 Volt
	301-7899	1	Late Portion of Spec C (Corner brace is part of output box)		320-0642	1	90 Amp, 240 Volt
	301-7899	1	Spec D				60 Hertz
5			Cover - Early Portion of Spec C (With 90° bend)		320-1061	1	Voltage Code 3R 125 Amp, 240 Volt
	301-7335	1	Without Circuit Breaker		320-1435	1	125 Amp, 240 Volt (With Shunt Trip)
			Opening		320-1440	1	Voltage Code 7R - 60 Amp, 480 Volt (With Shunt Trip)
			With Circuit Breaker				Voltage Code 15R
			Opening		320-0638	1	40 Amp, 480 Volt
	301-7516	1	Use with Westinghouse and General Electric Circuit Breakers		320-0645	1	50 Amp, 480 Volt
	301-7515	1	Use with Heineman Circuit Breakers		320-0384	1	60 Amp, 480 Volt
6			Cover		320-0647	1	70 Amp, 240 Volt
			Late Portion of Spec C (Without 90° Bend)		320-0700	1	80 Amp, 240 Volt
	301-7901	1	Without Circuit Breaker		320-0701	1	100 Amp, 240 Volt
			Opening		320-0457	1	100 Amp, 240 Volt (With Shunt Trip)
			With Circuit Breaker				125 Amp, 240 Volt
	301-7941	1	Use with Westinghouse and General Electric Circuit Breakers		320-1049	1	125 Amp, 240 Volt (With Shunt Trip)
	301-7942	1	Use with Heineman Circuit Breakers		320-1283	1	125 Amp, 240 Volt (With Shunt Trip)
			Spec D		320-1062	1	150 Amp, 240 Volt
	301-7901	1	Without Circuit Breaker		320-0344	1	175 Amp, 240 Volt
			Opening	13	517-0190	1	Plug, Plastic - 3-1/2" Hole
			With Circuit Breaker	14	301-7360	1	Bracket - Upper
	301-7941	1	Use with Westinghouse and General Electric Circuit Breakers	15	301-7361	1	Bracket - Lower
	301-7942	1	Use with Heineman Circuit Breakers	16	815-0567	2	Screw, Self-Tapping - Hex Head (5/16-18 x 1-1/4")
			Spec D	17	821-0010	14	Screw, Self-Locking - Hex Washer Head (1/4-20 x 1/2")
	301-7901	1	Without Circuit Breaker	18	815-0236	1	Screw, Self-Tapping - Hex Head (5/16-18 x 5/8")
			Opening	19	338-1649	1	Harness, Wiring - Engine to Control (Includes Grommet, Plug and Sockets)
			With Circuit Breaker				Grommet, Rubber - 1-1/2" Hole
	301-7941	1	Use with Westinghouse and General Electric Circuit Breakers	20	508-0258	1	Plug, Circular (16 Pin) (P1)
	301-7942	1	Use with Heineman Circuit Breakers	21	323-1134	1	Socket, Female
7	301-7572	1	Bracket, Mounting - Circuit Breaker	22			14-12 Gauge Wire
8	508-0257	1	Grommet, Plastic - 3-1/2" Hole		323-1192	4	18-14 Gauge Wire
9	338-1647	1	Harness, Wiring - Generator to Control (Includes Plug and Pins)		323-1195	10	Plug, Plastic - 3/8" Hole
				23	517-0169	4	Tie, Cable
				24	332-0941	3	


Output Box
(Spec C and D)



**Output Box
(Spec C and D)**

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
25	800-0007	1	Screw, Cap - Hex Head (1/4-20 x 1") Grounding Stud	45			Washer, Lock - IT (1/4")
26	856-0006	4	Washer, Lock - EIT (1/4")	854-0014	3		Single Phase Sets
27	526-0018	3	Washer, Flat (1/4")	854-0014	4		Three Phase Sets
28	862-0001	3	Nut, Hex (1/4-20)	46	821-0009	4	Screw, Self-Locking - Hex Washer Head (1/4-20 x 3/8")
29	821-0014	4	Screw, Self-Locking - Hex Washer Head (5/16-18 x 1/2")	47	800-0010	4	Screw, Cap - Hex Head (1/4-20 x 3/4")
30	850-0045	4	Washer, Lock - Spring (5/16")	48	332-1348	4	Spacer
31	526-0115	2	Washer, Flat (5/16")	49	870-0212	4	Nut, Self-Locking (1/4-20)
32	800-0024	4	Screw, Cap - Hex Head (5/16-18 x 1/2")	50	854-0014	4	Washer, Lock - IT (1/4")
33	517-0045	4	Plug, Dot Button - 9/32" Hole (Output boxes without terminal blocks)	51	800-0003	2	Screw, Cap - Hex Head (1/4-20 x 1/2")
34	508-0055	1	Grommet, Rubber - 1-3/4" Hole	52	850-0040	2	Washer, Lock - Spring (1/4")
35	301-8157	1	Bracket, Mounting	53	812-0094	4	Screw, Machine - Round Head (#8-32 x 3-5/8")
36			Transformer, Current (Ratio 75/5, 1VA) (CT21,22,23)	54	850-0025	4	Washer, Lock - Spring (#8)
	302-0076	2	Single Phase Sets	55	860-0008	4	Nut, Hex (#8-32)
	302-0076	3	Three Phase Sets	56	812-0063	6	Screw, Machine - Round Head (#6-32 x 1/2")
37			Shim	57	226-3423	6	Lead, Generator Output Extension
	302-0253	4	Single Phase Sets	58	812-0078	2	Screw, Machine - Round Head (#8-32 x 7/16")
	302-0253	6	Three Phase Sets	59	850-0025	2	Washer, Lock - Spring (#8)
38			Screw, Machine - Round Head (#10-32 x 2")	60	861-0007	2	Nut, Square (#8-32)
	813-0110	4	Single Phase Sets	61	812-0153	4	Screw, Machine - Round Head (1/4-20 x 1")
	813-0110	6	Three Phase Sets	62	850-0040	4	Washer, Lock - Spring (1/4")
39			Washer, Lock -IT (#10)	63	526-0052	4	Washer, Flat (1/4")
	854-0010	4	Single Phase Sets	64	308-0770	1	Switch, Tap - Dual Phase Selector (Includes Knob and Mounting Hardware)
	854-0010	6	Three Phase Sets	65	303-0218	1	Knob
40			Clamp - Upper	66	815-0166	4	Screw, Machine - Fillister Head (#10-32 x 1")
	302-0235	2	Single Phase Sets	67	870-0131	4	Nut, Hex - ET (#10-32)
	302-0235	3	Three Phase Sets	68	332-2634	3	Clamp, Insulated - DC Wiring Harness
41			Clamp - Lower	69	402-0070	4	Dampener, Vibration
	302-0236	2	Single Phase Sets	70	356-0090	2	Capacitor (1300 MFD) Used With Switching Voltage Regulator (C1)
	302-0236	3	Three Phase Sets	71	356-0102	2	Clamp, Mounting
42	332-2653	1	Block, Terminal				
43			Screw, Machine - Round Head				
	812-0160	1	1/4-20 x 2-1/2"				
			1/4-20 x 2"				
	812-0158	2	Single Phase Sets				
	812-0158	3	Three Phase Sets				
44			Nut, Self-Locking (1/4-20)				
	870-0212	6	Single Phase Sets				
	870-0212	8	Three Phase Sets				

Output Box (Spec E)




584A

Output Box (Spec E)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	319-0425	1	Box, Output	13	815-0236	1	Screw, Self-Tapping - Hex Head (5/16-18 x 5/8")
2	508-0257	1	Grommet, Plastic - 3-1/2" Hole	14	301-7899	1	Grille
3	338-2327	1	Harness, Wiring	15	517-0169	4	Plug, Plastic - 3/8" Hole
			Generator to Control (Includes Plug and Pins)	16	800-0007	1	Screw, Cap - Hex Head (1/4-20 x 1")
	338-2329	1	Engine to Control (Includes Parts Marked *)	17	856-0006	4	Washer, Lock - EIT (1/4")
4	323-1136	1	Plug, Circular (14 Pin) (P2)	18	526-0018	3	Washer, Flat (1/4")
5	323-1228	11	Pin, Male	19	862-0001	3	Nut, Hex (1/4-20)
6	508-0258	1	*Grommet, Rubber	20	850-0045	4	Washer, Lock - Spring (5/16")
7			*Housing, Connector	21	526-0115	2	Washer, Flat (5/16")
	323-1304	1	6 Place (J2)	22	800-0024	4	Screw, Cap - Hex Head (5/16-18 x 1/2")
	323-1306	1	8 Place (J1)	23	517-0045	4	Plug, Dot Button - 9/32" Hole
8	323-1200	12	*Socket, Female	24	301-7901	1	Cover
9	301-7360	1	Bracket - Upper	25	332-2634	3	Clamp, Insulated - DC Wiring Harness
10	301-7361	1	Bracket - Lower				
11	815-0567	2	Screw, Self-Tapping - Hex Head (5/16-18 x 1-1/4")				
12	821-0010	14	Screw, Self-Locking - Hex Washer Head (1/4-20 x 1/2")				

* - Parts Included in 338-2329 Wiring Harness.


Generator Heater



225A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	331-0041	2	Nut, Hex - Special
2	333-0157	1	Heater, Electrical
3	333-0228	1	Cord, Heater (6')


Control Heater (Spec C and D)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	335-0110	1	Cable, Electrical (3 Wire)
2	812-0090	2	Screw, Machine - Round Head (#6-32 x 2-1/4")
3	860-0006	4	Nut, Hex (#6-32)
4	856-0001	2	Washer, Lock - EIT (#6)
5	301-1886	1	Cover, Thermostat
6	309-0128	1	Thermostat - Adjustable
7	800-0007	2	Screw, Cap - Hex Head (1/4-20 x 1")

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
8	862-0001	2	Nut, Hex (1/4-20)
9	850-0040	2	Washer, Lock - Spring (1/4)
10	526-0052	2	Washer, Flat (17/64" ID x 9/16" OD x 1/16" Thk)
11	862-0015	4	Nut, Hex (5/16-18) - Used As Spacers
12	333-0151	1	Heater - 75 Watt, 120 VAC; 300 Watt, 240 VAC


Control Heater (Spec E)



574B

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	333-0151	1	Heater (HR1)	6	130-1107	2	Spacer
2	335-0161	1	Cable	7	812-0070	2	Screw, Machine - Round Head (#6-32 x 1-1/4")
3	800-0034	2	Screw, Cap - Hex Head (5/16-18 x 2-1/4")	8	854-0006	4	Washer, Lock - IT (#6)
4	526-0113	2	Washer, Flat (11/32" ID x 1" OD x 3/32" Thk)	9	860-0006	2	Nut, Hex (#6-32)
5	870-0257	2	Nut, Self-Locking - Hex Head (5/16-18)	10	870-0183	2	Nut, Hex - With ET (#6-32)
				11	301-1886	1	Cover
				12	309-0128	1	Thermostat

Control
(Spec C and D)




264D

Control (Spec C and D)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Regulator Assembly, Voltage (See Separate Page for Components)	18	338-1427	1	Harness, Wiring - Remote Control (30')
			Standard (VRA21)	19	815-0105	1	Screw, Machine - Round Head (Brass) (#10-32 x 1")
	305-0693-01	1	Fixed Resistor				Grounding Stud
	305-0693-02	1	External Adjust	20	526-0063	2	Washer, Flat - Brass (#10)
			Switching Regulator (VRA21)	21	856-0003	2	Washer, Lock - EIT (#10)
	305-0695-01	1	Fixed Resistor	22	851-0001	1	Washer, Lock - Spring (Brass) (#10)
	305-0695-02	1	External Adjust				Nut, Hex - Brass (#10-32)
	305-0737	1	Standard (VRAS-2)	23	871-0010	2	Screw, Self-Locking - Hex Washer Head (#10-32 x 1/2")
2			Bracket, Mounting - Relay	24	821-0005	5	Cover, Control
	301-3244	1	One Socket Hole				Box, Control
	301-7334	1	Two Socket Holes	25	301-5150	1	Panel, Control (See Separate Page for Components)
3	307-1061	1	Relay - Start (K11)	26	301-6230	1	Receptacle - Square Flange
4	307-1157	3	Spring, Holddown - Relay	27	-	1	14 Pin (J2)
5			Monitor Assembly, Engine (Includes Replaceable Relay and Spring) (A11)				16 Pin (J1)
			Two Light Monitoring System (Standard)	28	323-1137	1	Socket, Female - Used With 14 Pin Receptacle
	300-2510	1	Nine Light Monitoring System		323-1135	1	Pin, Male - Used With 16 Pin Receptacle
	300-2453-04	1		29	323-1229	11	16-12 Gauge Wire
6	307-1157	1	Spring, Holddown - Relay				18-14 Gauge Wire
7	307-1687	1	Relay (A11K1)	30			Plug - Circular
8	812-0061	2	Screw, Machine - Round Head (#6-32 x 3/8")		323-1193	4	14 Pin (P2)
					323-1194	12	16 Pin (P1)
9	854-0006	2	Washer, Lock - IT (#6)	31		1	Socket, Female - Used With 16 Pin Plug
10	860-0006	2	Nut, Hex (#6-32)		323-1136	1	14-12 Gauge Wire
11	307-1061	1	Relay - Voltage Selector (K21)		323-1134	1	18-14 Gauge Wire
			Relay - Run (K12)	32			Pin, Male - Used With 14 Pin Plug
12	307-1058	1	Socket, Relay (K12)		323-1192	4	
13	323-0804	1	Strap, Ground		323-1195	12	
14	337-0049	1	Washer, Lock - EIT (5/16")	33	323-1194	11	
15	856-0008	2	Grommet, Rubber (1" Hole)				
16	508-0144	1	Relay - Time Delay (Stop) (K15)				
17			1 Second to 5 Minutes				
	307-1151	1	3 to 30 Minutes				
	307-1194	1	6 to 60 Minutes				
	307-1189	1					


Control (Spec E)



Control (Spec E)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	319-0413	1	Cover, Control	27	338-1906	1	Harness, Wiring - Alarm Relay (7 and 12 Light Controls) (A13 to A11TB2)
2	402-0527	4	Isolator, Vibration				
3	508-0051	1	Grommet (2" Hole)	28			Board, Printed Circuit - Alarm Relay (7 and 12 Light Control) (A13)
4	337-0049	1	Strap, Ground		300-2862	1	12 VDC
5	862-0015	1	Nut, Hex (5/16-18)		300-2863	1	24 VDC
6	856-0008	1	Washer, Lock - EIT (5/16")	29			Screw, Machine - Round Head (#6-32 x 1/2")
7	-		Door Assembly, Control - AC (Left Hand Side Facing Control Doors) (See Separate Page for Components)		812-0063	4	7 Light Control
8	319-0416	1	Tray, Control		812-0063	8	12 Light Control
9	870-0131	6	Nut, Hex - ET (#10-32)	30	338-1905	1	Harness, Wiring - Alarm Relay (12 Light Control) (A14 to A11TB2)
10	871-0015	1	Nut, Hex (1/4-20) Grounding Stud	31	815-0544	4	Screw, Machine - Round Head - Cross Recessed with IT (#6-32 x 1/2")
11	853-0013	1	Washer, Lock - ET (1/4")	32			Board, Printed Circuit - Time Delay - Start/Stop/Preheat (A15)
12	338-2331	1	Harness, Wiring - AC (Includes Terminal Block) (AC Door Assembly to TB21 Terminal Block)				Without Preheat
13	332-0607	1	Block, Terminal - 12 Place (TB21)		300-2897	1	12 VDC
14	332-2723	1	Strip, Marker		300-2899	1	24 VDC
15	812-0065	2	Screw, Machine - Round Head (#6-32 x 5/8")				With Preheat
16	300-2880	1	Board, Voltage Regulator (Includes Jumper) (VR21)		300-2898	1	12 VDC
17	332-2605	1	Jumper, Terminal (VR21TB1-3 to -4) (W1)		300-2900	1	24 VDC
18	350-0394	1	Resistor (VR21TB1-7 to -8) (Controls Without Panel Voltage Adjust)	33	338-1904	1	Harness, Wiring - Time Delay Start/Stop (A15 to A11TB1)
19	815-0544	6	Screw, Machine - Round Head - Cross Recessed With IT (#6-32 x 1/2")	34	332-2957	1	Terminal, Tab (Double) (A15TB1-7)
20	-		Door Assembly, Control - DC (Right Hand Side Facing Control Doors) (See Separate Page for Components)	35	-		Board, Printed Circuit - Magnetic Pickup (A16) (See Separate Page for Part Number and Related Replacement Parts)
21	338-2330	1	Harness, Wiring - DC (Includes Connector Housing and Contact Pins) (DC Door Assembly to Engine Monitor)	36	812-0063	4	Screw, Machine - Round Head (#6-32 x 1/2")
22	323-1308	1	Housing, Connector - 12 Place (J4)	37			Board, Printed Circuit - Over/Under Voltage Sensor (A17)
23	323-1302	12	Pin, Contact		300-2905	1	12 VDC
24			Monitor, Engine (Includes Fuses) (A11)		300-2906	1	24 VDC
			7 Light Control	38	812-0063	4	Screw, Machine - Round Head (#6-32 x 1/2")
	300-2809	1	12 VDC	39	338-1940	1	Harness, Wiring - Over/Under Voltage Sensor (A17 to A11)
	300-2810	1	24 VDC	40	302-1833-01	1	Transducer, Watt (A21)
			12 Light Control	41	-		Heater, Control (See Separate Page for Components)
	300-2811	1	12 VDC	42	815-0544	4	Screw, Machine - Round Head - Cross Recessed with IT (#6-32 x 1/2")
	300-2812	1	24 VDC	43	813-0102	2	Screw, Machine - Round Head (#10-32 x 5/8")
25			Fuse	44	319-0030	1	Plate, Mounting - Transducer
	321-0270	2	20 Amp (F1,F2)	45	-		Relay, Run (See Separate Page for Components)
	321-0231	1	15 Amp (F3)				
	321-0094	2	5 Amp (F5)				
26			Board, Printed Circuit - Alarm Relay (12 Light Control) (A14)				
	300-2855	1	12 VDC				
	300-2856	1	24 VDC				


Voltage Regulator Assembly (VRA21 - Spec C and D)



195A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Regulator Assembly, Voltage - Complete	7	315-0343	1	Reactor - Used on Switching Voltage Regulator Assemblies (VRA21L22)
	305-0693-01	1	Fixed Resistor	8	315-0343	1	Reactor (VRA21L21)
	305-0693-02	1	External Adjust	9	332-0607	1	Block, Terminal (VRA21TB2)
			Switching Regulator	10	332-2373	1	Strip, Marker
	305-0695-01	1	Fixed Resistor	11	332-2387	4	Terminal, Tab - Used on Standard Voltage Regulator Assemblies
	305-0695-02	1	External Adjust				
1			Harness, Wiring	12	301-5736	1	Panel, Mounting
	338-1443	1	Standard Regulator	13			Screw, Machine - Round Head (#6-32 x 3/8")
	338-1670	1	Switching Regulator		812-0061	4	Standard Voltage Regulator Assemblies
2			Board, Voltage Regulator (VR21)		812-0061	6	Switching Voltage Regulator Assemblies
	332-2045	1	Standard Regulator (Includes Fuses)	14	870-0183	8	Nut, Self-Locking - Hex Head With ET Lockwasher (#6-32)
	300-2409	1	Switching Regulator	15	812-0070	2	Screw, Machine - Round Head (#6-32 x 1-1/4") Used on Standard Voltage Regulator Assemblies
3	321-0204	2	Fuse (1/4 Amp) Used With Standard Voltage Regulator Board (VR21F2,F3)				
4	350-1190	1	Resistor - Fixed (1740 Ohms, 1/2 Watt) Used on Voltage Regulator Assemblies Without External Adjust (VRA21R21)	16	812-0059	4	Screw, Machine - Round Head (#6-32 x 1/4")
5	315-0431	1	Transformer (VRA21T21)	17	853-0003	4	Washer, Lock - ET (#6)
6	305-0524	1	Bridge, Rectifier - Used on Standard Voltage Regulator Assemblies (VRA21CR21)	18	812-0065	2	Screw, Machine - Round Head (#6-32 x 5/8")


Voltage Regulator Assembly (VRAS-2 Spec C and D)



194A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	305-0737	1	Regulator Assembly, Voltage - Complete	6	332-0607	1	Block, Terminal (VRAS-2TB2)
1	301-9334	1	Panel, Mounting	7	812-0065	2	Screw, Machine - Round Head (#6-32 x 5/8")
2	812-0059	5	Screw, Machine - Round Head (#6-32 x 1/4")	8	870-0183	2	Nut, Self-Locking - Hex Head With ET Lockwasher (#6-32)
3	853-0003	5	Washer, Lock - ET (#6)	9	350-0394	1	Resistor - Fixed (2000 Ohms, 1/2 Watt) Used on Voltage Regulator Assemblies Without External Adjust (VRAS-2R21)
4	300-2880	1	Board, Voltage Regulator (VR21)				
5	332-2373	1	Strip, Marker				

Control Panel (Spec C and D)




273C

Control Panel (Spec C and D)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Panel, Control	19			Breaker, Circuit - Field
	301-7348-01	1	Panels Without AC Meters				Used With VRA21 Voltage
	301-7348-02	1	Panels With Three Round Gauge Holes	320-1138	1		Regulator Assembly
			Panels With Four Round Gauge Holes	320-0530	1		3 Amp (Dual - CB3,CB4)
	301-7349-01	1	Panels With AC Meters	320-1121	1		5 Amp (CB3)
			Panels With Three Round Gauge Holes				Used With VRAS-2 Voltage
	301-7349-02	1	Panels With Four Round Gauge Holes	20	302-0885	1	Regulator Assembly - 3 Amp (CB3)
2			Light, Indicator (14VDC)	21	302-1882	1	Meter, Time Totalizing (M4)
			Controls With Two Light Monitoring System	22	193-0330	1	Tachometer (Includes Socket and Lamp (M5))
	322-0238	1	RUN - Green (DS1)	23	302-1402	1	Gauge, Oil Temperature (M5)
	322-0128	1	FAULT - Red (DS2)	24	193-0352	1	Ammeter - DC (M1)
			Controls With Nine Light Monitoring System	25	193-0351	1	Gauge, Oil Pressure (M2)
	322-0238	1	RUN - Green (DS1)	26			Gauge, Water Temperature (M3)
	322-0110	1	LO ENG TEMP - Red (DS2)				Harness, Wiring - AC (Includes Socket for K11 Start Relay, Receptacle and Sockets)
	322-0109	1	HI ENG TEMP - Red (DS3)	338-1642-03	1		Controls Without AC Meters
	322-0108	1	LO OIL PRES - Red (DS4)				Controls With AC Meters
	322-0111	1	OVERSPEED - Red (DS5)	338-1642-02	1		Single Phase Sets
	322-0107	1	OVER CRANK - Red (DS6)				Three Phase Sets
	322-0240	1	PRE HI ENG TEMP - Amber (DS7)	338-1642-01	1		All Except Voltage Code 9XR (Also Includes Resistor and Socket for K21 Voltage Selector Relay)
	322-0241	1	PRE LO OIL PRESS - Amber (DS8)				Voltage Code 9XR
	322-0283	1	SWITCH OFF - Red (DS9)	338-1642-04	1		Socket, Relay (For K11,K21 Relays)
3	322-0141	7	Lens, Indicator Light (No Legend or Lamp) Controls With Two Light Monitoring System	27	323-0765	2	Resistor, Fixed - 47K Ohm, 1/2 Watt (K21R22)
4			Meter, Frequency - AC (M21)	28	350-0556	1	Harness, Wiring - DC (Includes Receptacle, Pins, Plug and Sockets, where required)
	302-1273	1	50 Hertz	29			
	302-1153	1	60 Hertz				
5			Ammeter - AC (M23)				
	302-1468	1	Single Phase Sets	338-1643-01	1		Meters
			Three Phase Sets	338-1644	1		Switches
	302-1147	1	All Except Voltage Code 9XR				Indicator Lights
	302-1298	1	Voltage Code 9XR	338-1646	1		Controls With Two Light Monitoring System
6			Voltmeter - AC (M22)				Controls With Nine Light Monitoring System
	302-1148	1	All Except Voltage Code 9XR	338-1645	1		
	302-1300	1	Voltage Code 9XR				
7			Switch, Push (Remote, Stop, Start) (S10)	30	322-0308	3	Lamp, Pilot (DS10,DS11,DS12)
			Controls With Two Light Monitoring System	31	322-0210	4	Socket, Lamp
			Controls With Nine Light Monitoring System	32	322-0004	1	Lamp, Pilot (DS13)
	308-0531	1	Standard	33	323-1137	1	Receptacle - Square Flange (14 Pin) (P2)
			Pennsylvania State Approved	34			Socket, Female
	308-0620	1	Switch, Push - Pre Heat (S11)	323-1229	11		Used With 338-1642-01 Wiring Harness
8	308-0533	1	Switch, Push - Lamp Test (S12)				Used With 338-1642-02 Wiring Harness
9	308-0532	1	Knob	323-1229	5		Used With 338-1642-03 Wiring Harness
10	303-0032	2	Potentiometer - 25 Watt (R23)				Used With 338-1642-04 Wiring Harness
11			Used With VRA21 Voltage Regulator Assembly With External Adjust	35	323-1135	1	Receptacle - Square Flange (16 Pin) (P1) Used With 338-1643-01 Wiring Harness
	303-0261	1	Used With VRAS-2 Voltage Regulator Assembly With External Adjust	36			Pin, Male - Used With 323-1137 Receptacle
12	308-0284	1	Switch, Rotary - Voltmeter/Ammeter (S21)				16-12 Gauge Wire
13			Light, Pilot (DS21,DS22)	323-1193	3		18-14 Gauge Wire
	322-0323	2	Single Phase Sets	323-1194	10		Plug, Connector (12 Pin) (J1, J2, J3) Used With 338-1643-01, 338-1644 and 338-1645 Wiring Harnesses
	322-0211	2	Three Phase Sets	37	323-0984	3	Socket, Male (Side Feed)
14	517-0132	1	Plug, Hole				Used With 338-1643-01 Wiring Harness
15	322-0203	2	Lamp (DS14,DS15)	38			Used With 338-1644 Wiring Harness
16	322-0213	2	Lampholder				Used with 338-1645 Wiring Harness
17	320-1110	1	Breaker, Circuit - Remote - 7 Amp (CB1)	323-0488	8		
18	320-1110	1	Breaker, Circuit - Control - 7 Amp (CB2)				
				323-0488	12		
				323-0488	10		


AC Control Door Assembly (Spec E)



570C

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	319-0417	1	Door, Control - AC Without Meters	10	303-0261	1	Potentiometer (R21)
	319-0418	1	Without Wattmeter	11	303-0032	1	Knob, Rotary Switch
	319-0419	1	With Wattmeter	12			Ammeter (M22)
2	302-1722	1	Wattmeter (Dial Not Included) (M24)		302-1473	1	0-50/100
3	302-1721-01	1	Dial, Wattmeter		302-1147	1	0-75/150
4	338-1936	1	Harness, Wiring - Watts Transducer (A21 to M24 and TB21)		302-1683	1	0-100/200
5	320-1121	1	Breaker, Circuit (CB21)		302-1684	1	0-150/300
6	322-0363	1	Light, Indicator - Upper/Lower Scale (DS21, DS22)		302-1685	1	0-200/400
7			Voltmeter (M21)		302-1724	1	0-250/500
	302-1148	1	0-300/600		302-1725	1	0-375/750
	302-1753	1	0-750		302-1726	1	0-400/800
8	308-0882	1	Switch, Rotary - Voltmeter/Ammeter (Knob Not Included) (S21)		302-1727	1	0-500/1000
9	302-1720	1	Meter, Frequency (Includes Resistor - Part Number Not Available at Time of Printing) (M23)		302-1728	1	0-600/1200
					302-1729	1	0-750/1500
					302-1798	1	0-1000/2000
					302-1799	1	0-1500/3000
					302-1800	1	0-2000/4000


DC Control Door Assembly (Spec E)



571C

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	319-0421	1	Door, Control - DC Doors with Three Round Gauge Holes	11	193-0352	1	Gauge, Oil Pressure (M11)
	319-0420	1	Doors with Five Round Gauge Holes	12	193-0351	1	Gauge, Water Temperature (M12)
2	815-0385	4	Screw, Machine - Round Head (#6-32 x 1/2")	13	302-1641	1	Voltmeter (M13)
3	870-0183	4	Nut, Hex - With ET (#6-32)		302-1642	1	12 VDC
4			Light Assembly, Indicator (Includes Wiring Harness and Connector Housing) (A12)	14	302-0885	1	24 VDC
			Seven Light Assembly	15	193-0330	1	Meter, Time Totalizing (M14)
	322-0359-01	1	12 VDC				Gauge, Oil Temperature
	322-0359-02	1	24 VDC				(Includes Mounting Clamp)
			Twelve Light Assembly	16			Tachometer (Part numbers for bulb and mounting hardware were not available at time of printing) (M16)
	322-0360-01	1	12 VDC		302-1873-01	1	12 VDC
	322-0360-02	1	24 VDC		302-1873-02	1	24 VDC
5			Light, Indicator - Replacement	17	193-0250	2	Resistor, Gauge (Used on 24 VDC Applications) (R12,R13)
	322-0369-01	1	12 VDC	18	308-0892	1	Switch, Rocker - Restart/Preheat/Panel Light (S11)
	322-0369-02	1	24 VDC	19	308-0784	1	Switch, Rocker - Run/Stop/Remote (S12)
6	322-0361	1	Light, Panel (DS11)	20	308-0853	1	Switch, Pushbutton - Emergency Stop (Part Number for Bulb Not Available at Time of Printing) (S14)
7			Bulb, Panel Light - Replacement				Latch, Panel
	322-0004	1	12 VDC	21	406-0661	2	Washer, Flat
	322-0017	1	24 VDC	22	526-0367	2	
8	302-0270	3	Clamp, Mounting				
9	526-0049	3	Washer, Flat (#10)				
10	871-0010	18	Nut, Hex - Brass (#10-32)				

Run Relay (Spec E)




577B

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Relay, Run (K11) (Quantity as Required)
	307-1058	1	12 VDC
	307-1056	1	24 VDC
2	815-0388	2	*Screw, Pan Head - Cross Recessed Thread (#6-32 x 1/2")

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
3	319-0447	1	Bracket, Relay Mounting
4	323-0804	1	*Socket, Relay
5	307-1987	2	*Holddown, Relay

* - Quantities listed are for one mounted relay.

Magnetic Pickup (Spec E)



578A

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	800-0003	2	Screw, Cap - Hex Head (1/4-20 x 1/2")
2	850-0040	2	Washer, Lock - Spring (1/4")
3	150-1410	1	Cap, Insulator
4	150-1406	1	Sensor, Speed - Magnetic
5	150-2117	1	Bracket and Point Assembly (Includes Parts Marked *)
6	862-0001	2	*Nut, Hex (1/4-20)
7	853-0013	1	*Washer, Lock - ET (1/4")
8	150-0723	1	*Point, Contact
9	870-0250	1	*Nut, Insulator
10	301-9402	1	*Bracket, Mounting
11	800-0053	1	Screw, Cap - Hex Head (3/8-16 x 1-3/4")
12	856-0010	1	Washer, Lock - EIT (3/8")
13	150-0717	1	Switch, Overspeed (S3)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
14	526-0077	1	Washer, Flat (3/8")
15	150-1557	1	Wheel, Sensor
16	370-4011	1	Spacer
17	854-0031	1	Washer, Lock - IT (3/4")
18			Board, Printed Circuit - Magnetic Pickup (A16)
	300-2901	1	12 VDC
	300-2903	1	24 VDC
19	338-1930	1	Harness, Wiring - Magnetic Pickup (A16 to A11)
20	868-0011	2	Nut, Hex - Jam (3/4-16)

* - Parts Included in 150-2117 Bracket and Point Assembly

Paint, Thread Sealant and Gasket Kits

REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	525-0305	-	Paint, Green - Enamel (13 oz. Pressurized Spray Can)
	518-0452	-	Sealant, Thread (50 cc Bottle)
	168-0173	1	Kit, Gasket - Lower End
	168-0160	1	Kit, Gasket - Valve Grind

Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
101-0471	7	110-2839	9	115-0315	9	140-1787	25
101-0511	7	110-2840	9	115-0316	9	140-1787	26
101-0592	32	110-2978	7	115-0320	23	140-1791	25
101-0600	7	110-2979	9	115-0346	23	140-1791	26
101-0630	32	110-2991	9	120-0885	11	140-1791	27
101-0677	7	110-3015	9	120-0917	20	140-1841	25
101-0678	7	110-3026	9	120-0920	9	140-1841	26
101-0679	7	110-3045	9	120-0979	11	140-1845	25
101-0680	7	110-3066	9	120-0983	11	140-1847	25
101-0681	7	110-3137	9	120-1006	20	140-1851	25
101-0682	7	110-3200	9	120-1014	11	140-1851	26
101-0683	7	110-3226-01	9	120-1041	11	140-2174	27
101-0684	7	110-3226-02	9	120-1063	11	140-2233	27
101-0685	7	110-3226-03	9	122-0550	22	140-2234	27
101-0686	7	110-3228	9	122-0613	22	140-2235	27
101-0687	7	110-3245	9	122-0635	22	140-2267	26
101-0688	7	110-3284	9	123-1511	7	142-0114	12
101-0689	7	110-3292	7	123-1514	7	147-0427	11
101-0690	7	110-3300	9	123-1518	23	147-0436	15
101-0691	7	110-3432	9	123-1524	20	147-0464-05	15
101-0692	7	110-3490	9	123-1536	9	147-0464-05	16
101-0713	7	110-3495	9	123-1558	23	147-0464-06	15
101-0740-01	32	110-3496	9	123-1605	23	147-0464-06	16
101-0740-02	32	112-0165	7	123-1647	23	147-0562	15
102-1036	20	112-0201	7	130-0755	40	147-0578	16
102-1147	21	112-0202	7	130-1107	65	147-0579	16
102-1190	20	112-0203	7	130-1818	45	147-0580	16
102-1235	21	112-0204	7	130-1873	45	147-0581	16
102-1237	21	112-0205	7	130-1922	45	147-0582	16
103-0716	11	113-0233	7	130-1928	45	147-0583	16
103-0731	11	113-0234	7	130-2150	45	147-0584	16
103-0733	11	113-0235	7	130-2154	45	147-0585	16
103-0735	11	113-0236	7	130-2158	45	147-0586	16
103-0746	11	113-0237	7	130-2160	45	147-0587	16
103-0750	11	114-0313	7	130-2201	43	147-0588	16
104-1138	7	114-0315	7	130-2202	43	147-0589	16
104-1171	33	114-0316	7	130-3007	43	147-0590	16
104-1472	31	114-0318	7	130-3008	43	147-0591	16
104-1503	33	114-0319	7	131-0294	31	147-0592	16
104-1576	7	114-0319-01	7	131-0324	31	147-0593	16
105-0508	11	114-0319-02	7	131-0335	31	147-0617	15
105-0512	7	114-0319-03	7	131-0342	31	147-0618	15
105-0513	11	115-0202	9	131-0351	31	147-0619	15
105-0515	7	115-0204	9	140-0722	25	147-0620	15
105-0519	11	115-0232	23	140-0722	26	147-0621	15
105-0534	7	115-0244	23	140-0752	41	147-0622	15
110-2752	9	115-0253	9	140-1089	24	147-0623	15
110-2781-01	9	115-0270	9	140-1091	24	147-0624	15
110-2781-02	9	115-0275	7	140-1260	27	147-0625	15
110-2781-03	9	115-0313	9	140-1559	27	147-0626	15

Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
147-0627	15	149-1952	19	159-1124	50	191-1559	35
147-0628	15	149-1953	19	159-1126	50	191-1560	35
147-0629	15	149-2040	18	160-1292	32	191-1598	43
147-0630	15	149-2045	19	168-0160	9	191-1888	36
147-0631	15	149-2046	19	168-0160	78	191-1888	37
147-0632	15	149-2047	19	168-0173	7	191-1893	37
147-0633	15	149-2067	17	168-0173	78	193-0244	39
147-0634	15	149-2069	17	191-0659	35	193-0250	75
147-0635	15	150-0717	55	191-0943	35	193-0318	31
147-0636	15	150-0717	77	191-1312	34	193-0322	45
147-0637	15	150-0723	55	191-1321	34	193-0330	73
147-0638	15	150-0723	77	191-1332	34	193-0330	75
147-0639	15	150-0939	13	191-1339	34	193-0351	73
147-0640	15	150-1406	77	191-1394	36	193-0351	75
147-0641	15	150-1410	77	191-1394	37	193-0352	73
147-0642	15	150-1445	55	191-1430	37	193-0352	75
147-0643	15	150-1446	55	191-1431	37	193-0353	22
147-0644	15	150-1557	77	191-1432	37	201-2152	55
147-0645	15	150-1923	13	191-1433	37	201-2298	55
147-0646	15	150-1996	13	191-1434	37	201-2947	55
147-0647	15	150-2117	77	191-1435	37	201-2955	55
147-0666	15	151-0230	12	191-1436	37	201-2956	55
147-0667	15	151-0437	13	191-1437	37	201-3048	55
147-0668	15	151-0565	13	191-1438	37	201-3049	55
147-0669	15	151-0566	13	191-1439	37	201-3050	55
147-0670	15	151-0567	13	191-1440	37	205-0132	55
147-0671	15	151-0603-02	13	191-1441	37	211-0349	55
147-0672	15	152-0157	12	191-1442	37	220-2010	55
147-0673	15	152-0158	12	191-1443	37	220-2309	55
147-0674	15	152-0282	12	191-1444	37	220-3532	55
147-0765	15	154-2162	29	191-1445	37	220-3533	55
147-0766	15	154-2300	28	191-1446	37	220-3559	55
147-0767	15	154-2325	29	191-1449	37	220-3560	55
148-0274	12	154-2389	29	191-1450	37	220-3561	55
149-1728	17	154-2461	28	191-1452	35	220-3587	55
149-1732	17	154-2604	28	191-1453	35	220-3588	55
149-1754	17	155-1430	41	191-1454	35	220-3589	55
149-1755	17	155-1614	41	191-1457	35	220-3590	55
149-1796	17	155-1916	29	191-1525	34	220-3591	55
149-1797	17	155-1920	29	191-1525	35	220-3607	55
149-1801	17	155-1931	41	191-1539	45	220-3608	55
149-1828	47	155-1936	41	191-1540	45	220-3609	55
149-1835	17	159-0007	47	191-1541	34	220-3768	55
149-1836	17	159-0007	49	191-1542	45	220-3769	55
149-1908-05	18	159-0007	50	191-1543	45	220-3998	55
149-1908-05	19	159-1120	47	191-1546	45	220-4086	55
149-1914-01	18	159-1120	49	191-1547	45	220-4102	55
149-1914-01	19	159-1122	47	191-1556	35	226-3423	59
149-1922	18	159-1122	49	191-1557	35	232-2398	55
149-1949	19	159-1123	50	191-1558	35	232-2418	55

Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
232-2584	55	301-7941	57	303-0261	74	309-0458	31
232-2843	55	301-7942	57	305-0524	70	309-0462	31
232-2845	55	301-8157	59	305-0693-01	67	309-0473	30
300-2409	70	301-9334	71	305-0693-01	70	309-0561	39
300-2453-04	67	301-9402	77	305-0693-02	67	315-0343	70
300-2510	67	302-0076	59	305-0693-02	70	315-0431	70
300-2809	69	302-0235	59	305-0695-01	67	319-0030	69
300-2810	69	302-0236	59	305-0695-01	70	319-0413	69
300-2811	69	302-0253	59	305-0695-02	67	319-0416	69
300-2812	69	302-0270	75	305-0695-02	70	319-0417	74
300-2855	69	302-0885	73	305-0737	67	319-0418	74
300-2856	69	302-0885	75	305-0737	71	319-0419	74
300-2862	69	302-1147	73	307-0565	49	319-0420	75
300-2863	69	302-1147	74	307-1031	51	319-0421	75
300-2880	69	302-1148	73	307-1056	76	319-0425	61
300-2880	71	302-1148	74	307-1058	47	319-0447	76
300-2897	69	302-1153	73	307-1058	49	320-0344	57
300-2898	69	302-1273	73	307-1058	67	320-0384	57
300-2899	69	302-1298	73	307-1058	76	320-0457	57
300-2900	69	302-1300	73	307-1061	67	320-0530	73
300-2901	77	302-1402	73	307-1151	67	320-0540	13
300-2903	77	302-1468	73	307-1157	47	320-0638	57
300-2905	69	302-1473	74	307-1157	49	320-0638	57
300-2906	69	302-1641	75	307-1157	67	320-0642	57
301-1886	64	302-1642	75	307-1166	51	320-0645	57
301-1886	65	302-1683	74	307-1189	67	320-0647	57
301-3244	67	302-1684	74	307-1194	67	320-0700	57
301-5150	67	302-1685	74	307-1687	67	320-0701	57
301-5736	70	302-1720	74	307-1886	13	320-1049	57
301-6230	67	302-1721-01	74	307-1987	76	320-1061	57
301-7334	67	302-1722	74	308-0284	73	320-1062	57
301-7335	57	302-1724	74	308-0531	73	320-1110	73
301-7336	57	302-1725	74	308-0532	73	320-1121	73
301-7348-01	73	302-1726	74	308-0533	73	320-1121	74
301-7348-02	73	302-1727	74	308-0620	73	320-1138	73
301-7349-01	73	302-1728	74	308-0624	73	320-1283	57
301-7349-02	73	302-1729	74	308-0770	59	320-1435	57
301-7360	57	302-1753	74	308-0784	75	320-1440	57
301-7360	61	302-1798	74	308-0853	75	321-0094	69
301-7361	57	302-1799	74	308-0882	74	321-0204	70
301-7361	61	302-1800	74	308-0892	75	321-0231	69
301-7381	57	302-1833-01	69	309-0128	64	321-0270	69
301-7515	57	302-1873-01	75	309-0128	65	322-0004	73
301-7516	57	302-1873-02	75	309-0169	39	322-0004	75
301-7572	57	302-1882	73	309-0269	9	322-0017	75
301-7899	57	303-0032	73	309-0272	39	322-0107	73
301-7899	61	303-0032	74	309-0410	49	322-0108	73
301-7901	57	303-0170	73	309-0424	30	322-0109	73
301-7901	61	303-0218	59	309-0436	31	322-0110	73
301-7903	57	303-0261	73	309-0437	31	322-0111	73

Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
322-0128	73	323-1302	69	338-1670	70	415-0451	47
322-0141	73	323-1304	61	338-1691	45	415-0451	49
322-0203	73	323-1306	61	338-1705	13	415-0466	49
322-0210	73	323-1308	69	338-1765-01	13	415-0467	49
322-0211	73	331-0041	63	338-1904	69	415-0516	49
322-0213	73	332-0602	51	338-1905	69	415-0543	49
322-0238	73	332-0607	69	338-1906	69	416-0530	36
322-0240	73	332-0607	70	338-1930	77	416-0618	36
322-0241	73	332-0607	71	338-1936	74	416-0812	51
322-0283	73	332-0941	57	338-1940	69	416-0813	51
322-0308	73	332-1281	34	338-2329	61	416-0821	51
322-0323	73	332-1292	34	338-2330	69	501-0003	18
322-0359-01	75	332-1348	59	338-2331	69	501-0007	47
322-0359-02	75	332-1473	51	350-0394	69	501-0027	47
322-0360-01	75	332-2045	70	350-0394	71	501-0027	49
322-0360-02	75	332-2373	70	350-0556	73	501-0027	50
322-0361	75	332-2373	71	350-1190	70	501-0094	15
322-0363	74	332-2387	70	356-0090	59	501-0094	50
322-0369-01	75	332-2605	69	356-0102	59	501-0441	17
322-0369-02	75	332-2634	59	358-0069	55	501-0482	21
323-0488	73	332-2634	61	358-0070	55	502-0003	9
323-0765	47	332-2653	59	370-4011	77	502-0003	47
323-0765	49	332-2723	69	402-0070	59	502-0003	49
323-0765	73	332-2957	69	402-0078	47	502-0003	50
323-0804	67	333-0151	64	402-0078	49	502-0020	18
323-0804	76	333-0151	65	402-0466	51	502-0020	49
323-0984	73	333-0157	63	402-0527	69	502-0029	18
323-1134	57	333-0202	40	403-1925	38	502-0041	18
323-1134	67	333-0204	40	403-1929	51	502-0041	47
323-1135	67	333-0220	38	403-1932	38	502-0041	49
323-1135	73	333-0228	63	403-2053	51	502-0041	50
323-1136	57	335-0110	64	403-2064	53	502-0057	15
323-1136	61	335-0161	65	405-1872	53	502-0153	17
323-1136	67	336-4131	38	405-2677	53	502-0153	19
323-1137	67	337-0049	67	405-2823	53	502-0153	30
323-1137	73	337-0049	69	405-3060	53	502-0153	45
323-1192	57	337-0090	51	405-3070	53	502-0156	30
323-1192	67	338-1427	67	405-3082	53	502-0317	31
323-1193	67	338-1443	70	405-3306	53	502-0415	21
323-1193	73	338-1642-01	73	405-3809	45	502-0613	40
323-1194	67	338-1642-02	73	406-0369	53	502-0733	15
323-1194	73	338-1642-03	73	406-0490	53	502-0736	17
323-1195	57	338-1642-04	73	406-0491	53	502-0738	17
323-1195	67	338-1643-01	73	406-0493	53	502-0773	17
323-1200	61	338-1644	73	406-0561	53	502-0774	17
323-1228	57	338-1645	73	406-0661	75	502-0775	31
323-1228	61	338-1646	73	415-0321	47	502-0876	21
323-1229	67	338-1647	57	415-0326	47	503-0183	40
323-1229	73	338-1647	61	415-0326	49	503-0354	25
323-1236	45	338-1649	57	415-0445	47	503-0365	45

Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
503-0382	21	508-0144	67	526-0063	49	718-1801	28
503-0429	45	508-0228	9	526-0063	67	718-1802	38
503-0465	24	508-0250	21	526-0077	55	720-1072	29
503-0465	27	508-0257	57	526-0077	77	720-1072	51
503-0625	26	508-0257	61	526-0113	65	720-1123	31
503-0648	24	508-0258	57	526-0115	59	720-1801	7
503-0832	40	508-0258	61	526-0115	61	720-1802	9
503-0867	26	509-0094	55	526-0219	51	720-1804	33
503-1053	17	509-0142	23	526-0249	55	720-1806	36
503-1054	17	509-0191	11	526-0283	31	725-1051	22
503-1055	17	509-0203	7	526-0367	75	725-1056	30
503-1070	45	509-0263	11	526-2100	45	725-1074	17
503-1074	27	509-0264	31	526-2106	11	725-1801	11
503-1084	27	509-0265	16	526-2106	15	725-1802	11
503-1143	27	510-0112	55	526-2106	34	740-1004	7
503-1170	40	515-0094	55	526-2107	11	740-1004	17
503-1177	45	515-0245	7	526-2108	22	740-1006	7
503-1181	24	515-0245	31	526-2119	9	740-1006	11
503-1222	25	516-2102	7	526-2123	41	740-1006	20
503-1222	26	517-0045	59	526-2127	11	740-1006	25
503-1276	21	517-0045	61	541-0214-04	31	740-1006	28
504-0003	45	517-0132	73	541-0286	20	740-1006	29
504-0011	21	517-0140	7	718-1002	36	740-1006	31
504-0028	7	517-0141	7	718-1019	55	740-1008	9
505-0007	47	517-0142	9	718-1021	17	740-1008	17
505-0007	49	517-0144	7	718-1021	43	740-1008	33
505-0007	50	517-0146	7	718-1032	45	740-1008	34
505-0016	49	517-0146	9	718-1035	11	740-1010	11
505-0017	30	517-0162	9	718-1035	31	740-1010	25
505-0054	47	517-0167	9	718-1035	45	740-1010	36
505-0054	49	517-0169	57	718-1036	11	740-1010	38
505-0054	50	517-0169	61	718-1036	20	740-1014	32
505-0059	39	517-0190	57	718-1036	25	740-1801	7
505-0098	39	517-0250	7	718-1036	40	740-1801	9
505-0098	49	517-0263	45	718-1037	7	740-1801	32
505-0110	47	518-0409	7	718-1037	11	750-1002	38
505-0110	49	518-0452	78	718-1037	34	750-1004	43
505-0120	40	520-0055	55	718-1039	11	750-1006	15
505-0131	40	520-0966	55	718-1042	28	750-1006	25
505-0135	40	520-2403	15	718-1043	11	775-0074	7
505-0274	7	525-0305	78	718-1044	11	775-0078	7
505-0274	22	526-0003	53	718-1044	31	775-0089	7
505-0274	28	526-0008	55	718-1046	11	800-0002	49
505-0454	41	526-0018	59	718-1046	20	800-0003	45
505-0949	50	526-0018	61	718-1047	45	800-0003	59
505-1050	49	526-0021	45	718-1048	11	800-0003	77
505-2012	32	526-0049	75	718-1064	11	800-0004	55
508-0015	34	526-0052	12	718-1073	25	800-0006	13
508-0051	69	526-0052	59	718-1078	32	800-0007	59
508-0055	59	526-0052	64	718-1086	38	800-0007	61


Numerical Index

Part No.	Page	Part No.	Page	Part No.	Page	Part No.	Page
800-0007	64	813-0102	69	850-0040	77	862-0001	53
800-0010	59	813-0103	12	850-0045	59	862-0001	55
800-0024	59	813-0103	13	850-0045	61	862-0001	59
800-0024	61	813-0110	59	850-0050	55	862-0001	61
800-0034	65	815-0104	12	850-0060	51	862-0001	64
800-0036	41	815-0105	67	850-0060	53	862-0001	77
800-0051	55	815-0166	59	850-2005	36	862-0003	55
800-0053	77	815-0194	55	850-2005	38	862-0015	64
800-0090	51	815-0236	57	850-2006	43	862-0015	69
800-0090	53	815-0236	61	850-2006	55	862-0016	51
800-0091	51	815-0385	75	850-2008	34	862-0016	53
800-2029	43	815-0388	76	850-2008	36	868-0011	77
800-2056	43	815-0544	69	850-2008	40	870-0048	47
800-2060	34	815-0547	20	850-2008	43	870-0048	49
800-2071	13	815-0567	57	850-2008	45	870-0131	12
800-2085	9	815-0567	61	850-2010	55	870-0131	13
800-2085	55	815-0578	11	850-2012	18	870-0131	55
800-2087	55	815-0612	31	850-2012	29	870-0131	59
800-2100	34	818-0150	53	850-2012	51	870-0131	69
800-2110	18	821-0004	53	851-0001	67	870-0183	65
800-2110	36	821-0005	67	853-0003	70	870-0183	70
800-2110	51	821-0009	59	853-0003	71	870-0183	71
800-2524	29	821-0010	45	853-0008	55	870-0183	75
802-0040	55	821-0010	50	853-0013	55	870-0196	34
805-0025	55	821-0010	51	853-0013	69	870-0212	12
809-0035	34	821-0010	53	853-0013	77	870-0212	45
812-0059	70	821-0010	55	853-2012	36	870-0212	47
812-0059	71	821-0010	57	853-2012	51	870-0212	51
812-0061	47	821-0010	61	854-0006	65	870-0212	53
812-0061	49	821-0013	47	854-0006	67	870-0212	59
812-0061	67	821-0013	49	854-0010	59	870-0250	55
812-0061	70	821-0013	51	854-0014	59	870-0250	77
812-0063	59	821-0014	27	854-0031	77	870-0257	18
812-0063	69	821-0014	47	856-0001	64	870-0257	26
812-0065	69	821-0014	49	856-0003	67	870-0257	27
812-0065	70	821-0014	59	856-0006	51	870-0257	40
812-0065	71	821-0016	26	856-0006	59	870-0257	41
812-0070	65	821-0016	40	856-0006	61	870-0257	65
812-0070	70	821-0018	12	856-0008	67	870-0258	53
812-0078	59	821-0018	47	856-0008	69	870-0284	55
812-0090	64	821-2076	27	856-0010	34	870-1183	47
812-0094	59	850-0025	59	856-0010	55	870-1183	49
812-0148	53	850-0030	13	856-0010	77	871-0010	67
812-0153	59	850-0030	47	860-0006	64	871-0010	75
812-0158	59	850-0030	49	860-0006	65	871-0015	69
812-0160	59	850-0040	13	860-0006	67	895-0195	53
813-0098	47	850-0040	53	860-0008	59		
813-0098	49	850-0040	55	860-2008	36		
813-0098	53	850-0040	59	860-2009	34		
813-0100	55	850-0040	64	861-0007	59		

HARDWARE IDENTIFICATION


Illustrated hardware items are only for identification purposes. All hardware items listed throughout this parts catalog are steel SAE grade five (5) or lower (zinc plated with clear chromate dip) unless parts description indicates differently. All dimensions are in inches.

WASHER TYPES





- * - Flat washer dimensions given are: Inside Diameter (ID), Outside Diameter (OD) and Thickness (Thk).

BOLT AND SCREW TYPES



L - Measure length between these points.

INTERNAL DRIVE TYPES



NUT TYPES





Onan Corporation
1400 73rd Avenue N.E.
Minneapolis, Minnesota 55432

Telephone: (612) 574-5000
Telex: 275477
Cable ONAN